


#### **Key Features of Tronics-EVB3**

- Printed Circuit Board for evaluation of GYPRO<sup>®</sup> and AXO<sup>®</sup> products
- Includes 1 inertial sensor and external passive components
- Plug and Play SPI interface, compatible with Arduino Leonardo and Yùn
- RS422 and USB interfaces for Arduino boards
- 5V single power supply
- 5V, 3.3V and 1.8V compatibility for communication interface



#### **1. General Description**

Tronics-EVB3 evaluation board is intended to easily and quickly perform characterizations of GYPRO4100 gyro and AXO315 accelerometer. Tronics-EVB3 was specially designed to be interfaced with an Arduino M0 or Arduino Yùn boards. The combination of Tronics-EVB3 with the Arduino platform is ideally suited for tests with rate table over the temperature range [-40°C to +85°C].


The 1.8V, 3.3V and 5V compatibility for SPI communication also enables connecting the Tronics-EVB3 with most of the acquisition systems and microcontrollers in the market.


This document describes the mechanical and electrical features of the Tronics-EVB3 board as well as the SPI protocol used for the digital communication. This document is applicable to the whole AXO product line, including AXO315 accelerometers, and GYPRO4100 gyros.

For more information about performances of each product, please refer to the dedicated datasheet, available on our <u>website</u>.

### 2. Mechanical features

The evaluation board has the following dimensions:







The main GYPRO®AXO®-EVB3 components are described in the table 1:

Name	Description	Information		
		Tronics-EVB3 I/O signals		
		Enable pin: EN		
J1	I/O connector	Self-Test pin: ST		
		SPI Slave select: SSB		
		Data Ready pin: DRDY		
J2	I/O connector	Arduino UART signals (RX and TX)		
J3	I/O connector	Tronics reserved		
J4	I/O connector	Not used		
J5	I/O connector	Power supply: 5V, VDDIO, GND		
J6	I/O connector	Power supply lines: 5V, GND		
10	,	SPI lines: MOSI, MISO, SCLK		
J7	GYPRO <sup>®</sup> or AXO <sup>®</sup> Product	Tronics inertial sensor		
J8	I/O connector	RS422 connector (RX+, RX-, TX+, TX-, GND)		
		SPI level voltage reference:		
19	I/O connector	<ul> <li>With jumper on +5V : SPI level = +5V</li> </ul>		
		<ul> <li>With jumper on 3V3/EXT : SPI level = VDDIO</li> </ul>		
		Sensor reset:		
J10	I/O connector	Without jumper: no reset		
		With jumper: reset		

Table 1: Main components description

Please note that the PCB has a flat backside and thickness of 1.6 mm. The board has been designed for a direct mounting onto the surface of your test equipment (rate table, vibration shaker...) in order to avoid parasitic mechanical resonance of the PCB.

## 3. Pins configuration and description

To enable compatibility with the Arduino platform, some signals are redundant, such as 5V and GND signals. If you don't intend to use the Arduino platform, redundancy is not necessary. However the pins marked with bold characters in the tables below must absolutely be connected.

J1 gives access to the following signals:

Pin #	Name	Туре	Function
#1	-	-	Not Connected
#2	-	-	Not Connected
#3	-	-	Not Connected
#4	GND	Power	Ground Power Supply
#5	-	-	Not Connected
#6	DRDY	Output	Data Ready pin
#7	SSB	Input	SPI Slave Select pin
#8	-	-	Not Connected
#9	ST	Output	Self-test pin
#10	EN	Input	Enable pin

J2 gives access to the following signals:

Pin #	Name	Туре	Function
#1	RX	Input	Arduino UART RX
#2	ТΧ	Output	Arduino UART TX
#3	-	-	Not Connected
#4	-	-	Not Connected
#5	-	-	Not Connected
#6	-	-	Not Connected
#7	-	-	Not Connected
#8	-	-	Not Connected

J3 gives access to the following signals:

Pin #	Name	Туре	Function
#1	Т0	Output	Tronics Reserved
#2	T1	Output	Tronics Reserved
#3	T2	Output	Tronics Reserved
#4	Т3	Output	Tronics Reserved

J4 gives access to the following signals:

Pin #	Name	Туре	Function
#1	-	-	Not Connected
#2	-	-	Not Connected
#3	-	-	Not Connected
#4	-	-	Not Connected
#5	-	-	Not Connected
#6	-	-	Not Connected

J5 gives access to the following signals:

Pin #	Name	Туре	Function
#1	-	-	Not Connected
#2	-	-	Not Connected
#3	-	-	Not Connected
#4	3V3 / EXT	Power	VDDIO Power Supply
#5	5V	Power	5V Power Supply
#6	GND	Power	Ground Power Supply
#7	GND	Power	Ground Power Supply
#8	-	-	Not Connected

J6 gives access to the following signals:

Pin #	Name	Туре	Function
#1	5V	Power	5V Power Supply
#2	MOSI	Input	SPI data input
#3	GND	Power	Ground Power Supply
#4	MISO	Output	SPI data output
#5	SCLK	Input	SPI serial clock
#6	-	-	Not Connected

J8 gives access to the following signals:

Pin #	Name	Туре	Function
#1	TX+	Output	Arduino RS422 TX+
#2	TX-	Output	Arduino RS422 TX-
#3	RX-	Input	Arduino RS422 RX-
#4	RX+	Input	Arduino RS422 RX+
#5	GND	Power	Ground Power Supply
#6	5V	Power	Ground Power Supply

For more information about the RS422 interface and its use, please refer to the dedicated technical notes, available on our <u>website</u>

# 4. Electrical circuit

The following figure presents the electrical schematic of the board with its passive components (resistors & capacitances).




Figure 2: Electrical schematic