



Qorivva MPC5744P Evaluation Board 144LQFP Expansion Board User's Guide

by: Barbara Johnson
Applications Engineering

1 Introduction

This document describes the Qorivva MPC5744P evaluation board (EVB) expansion board for the 144LQFP (part number MPC5744P-144DC). The EVB is targeted at providing a platform for the evaluation and development of the MPC5744P automotive MCU, facilitating hardware and software development as well as debugging. Settings for switches, jumpers, LEDs, and push-buttons are shown for basic operation of the prototype version of the EVB.

This document is preliminary and is subject to change without notice.

2 Features

The expansion board provides the following primary features listed below:

- Standalone operation or use with the optional MPC5746MMB main board

Contents

1	Introduction	1
2	Features	1
3	Modular concept	2
3.1	Methods of operation	3
4	EVB configuration	3
4.1	Power source	3
4.2	VPP_TEST	7
4.3	Boot configuration	8
4.4	Clocks	8
4.5	I/O connectivity	9
4.6	Main board I/O power	11
4.7	PwrSBC settings	12
5	Reset switches	13
6	Connectors	13
6.1	JTAG connector	14
6.2	Nexus parallel trace connector	14
6.3	Main board interface	15
7	LEDs	19
8	Test points	20
9	Port pin to main board mapping	20
10	Diagrams	25
11	Revision history	28

Modular concept

- Socketed MPC5744P in 144-pin LQFP package
- Power options
 - Power supplied via the two interface connectors when using the EVB with the optional MPC5746MMB main board
 - Power supplied via terminal block when using the EVB in standalone configuration
 - Power supplied by the multi-output MC33907 PwrSBC power supply when using the EVB in standalone configuration
- Debug and trace
 - JTAG connector
 - Nexus parallel connector
- Clocks
 - 40 MHz crystal
 - 8 MHz crystal oscillator
 - SMA connector for external clock
- I/O connectivity
 - Access to port pins when using the EVB with the optional MPC5746MMB main board
 - Access to SCI, CAN, and LIN physical interfaces when using the EVB with the optional MPC5746MMB main board
 - On-board CAN and LIN interfaces
- Switches
 - Main power on/off
 - Power-on reset
 - Reset
- LEDs for power indication
- Test points

3 Modular concept

The MPC5744P-144DC is part of a modular EVB hardware system that consists of:

- A common main board that provides power and access to common communication interfaces and the MCU I/O port pins. MPC5744P-144DC is compatible with the MPC5746MMB main board.
- A package-specific expansion board to support available package types of the MPC5744P. The MPC5744P-144DC supports the 144-pin LQFP package.




Figure 1. MPC5744P expansion board and main board system

3.1 Methods of operation

Power to the expansion board is supplied via three options:

1. The MPC5746MMB main board generates the 5 V/3.3 V/1.25 V supplies to the expansion board via the interface connectors.
2. In standalone configuration, external 5 V/3.3 V/1.25 V supplies are provided to the expansion board via the terminal block.
3. In standalone configuration, a single 12 V supply is input to the expansion board via the 2.1 mm power connector. The PwrSBC generates the 5 V/3.3 V high-voltage power. The NPN transistor drives the core supply using internal regulation.¹

4 EVB configuration

This section provides information on how to configure the jumper settings on the EVB. Default settings are marked as such. Figure 5 provides a top view of the EVB and shows the location of each jumper.

4.1 Power source

The default jumper settings are configured for using the EVB with the MPC5746MMB main board as shown in Figure 2. Power is supplied from the main board to the EVB via the two interface connectors.

1. Not all expansion boards include the PwrSBC device. Check whether the PwrSBC (U3) is installed on the expansion board to determine whether standalone operation using a single 12 V supply can be used. Refer to Figure 5 for the location of U3.

EVB configuration

The EVB can also operate as a standalone device, in which power can be supplied from an external power source or from the on-board PwrSBC device.

Table 1 summarizes the switch settings for the three power options.

Table 1. Switch settings — power options

Jumper	Setting	Description
J1	Choose one: 2-4 ON 3-4 ON 4-6 ON	High voltage I/O power VDD_HV_IO — 3.3 V from PwrSBC VDD_HV_IO — 3.3 V from main board (default) VDD_HV_IO — 3.3 V from external supply
J3	Choose one: 2-4 ON 3-4 ON 4-6 ON	High voltage flash power VDD_HV_FLA0 — 3.3 V from PwrSBC VDD_HV_FLA0 — 3.3 V from main board (default) VDD_HV_FLA0 — 3.3 V from external supply
J19	Choose one: 2-4 ON 3-4 ON 4-6 ON	High voltage oscillator power VDD_HV_OSC0 — 3.3 V from PwrSBC VDD_HV_OSC0 — 3.3 V from main board (default) VDD_HV_OSC0 — 3.3 V from external supply
J20	Choose one: 2-4 ON 3-4 ON 7-8 ON 6-8 ON 8-10 ON	High voltage ADC0/2 reference VDD_HV_ADR0 — from PwrSBC, see J24 VDD_HV_ADR0 — 3.3 V from main board (default) VDD_HV_ADR0 — 5 V from main board VDD_HV_ADR0 — 3.3 V from external supply VDD_HV_ADR0 — 5 V from external supply
J21	Choose one: 2-4 ON 3-4 ON 7-8 ON 6-8 ON 8-10 ON	High voltage ADC1/3 reference VDD_HV_ADR1 — from PwrSBC (see J24) VDD_HV_ADR1 — 3.3 V from main board (default) VDD_HV_ADR1 — 5 V from main board VDD_HV_ADR1 — 3.3 V from external supply VDD_HV_ADR1 — 5 V from external supply
J24	Choose one: 2-4 ON 1-3 ON	5 V/3.3 V select for ADC reference VDD_HV_ADR0 and VDD_HV_ADR1 — 3.3 V from PwrSBC (default) VDD_HV_ADR0 and VDD_HV_ADR1 — 5 V from PwrSBC
J22	Choose one: 2-4 ON 3-4 ON 4-6 ON	High voltage ADC power VDD_HV_ADV0/1 — 3.3 V from PwrSBC VDD_HV_ADV0/1 — 3.3 V from main board (default) VDD_HV_ADV0/1 — 3.3 V from external supply
J23	Choose one: 2-4 ON 3-4 ON 4-6 ON	High voltage PMU supply VDD_HV_PMU — 3.3 V from PwrSBC VDD_HV_PMU — 3.3 V from main board (default) VDD_HV_PMU — 3.3 V from external supply
J16	Choose one: 2-4 ON 3-4 ON 4-6 ON	Low voltage supply VDD_LV_CORE — use NPN transistor, internal regulation VDD_LV_CORE — 1.25 V from main board, external regulation (default) VDD_LV_CORE — 1.25 V from external supply, external regulation

4.1.1 Option 1: Power from the MPC5746MMB main board

The default configuration for the EVB power source is the main board.

In this configuration, the EVB is connected to the main board. The main board must be supplied with a 12 V input via the 2.1 mm barrel connector (P26) or the terminal block (P33). Voltage regulators on the main board provide 5 V, 3.3 V, and 1.25 V to the MCU via the high-density expansion connectors. The MCU core supply can be externally regulated or internally regulated using the NPN transistor.




Figure 2. Power from the main board

Table 2 shows the switch settings when power is sourced from the main board.

Table 2. Switch settings — power from main board

Jumper	Setting	Description
J1	3–4 ON	VDD_HV_IO — 3.3 V from main board (default)
J3	3–4 ON	VDD_HV_FLA0 — 3.3 V from main board (default)
J19	3–4 ON	VDD_HV_OSC0 — 3.3 V from main board (default)
J20	Choose one: 3–4 ON 7–8 ON	VDD_HV_ADR0 — 3.3 V from main board (default) VDD_HV_ADR0 — 5 V from main board
J21	Choose one: 3–4 ON 7–8 ON	VDD_HV_ADR1 — 3.3 V from main board (default) VDD_HV_ADR1 — 5 V from main board
J22	3–4 ON	VDD_HV_ADV0/1 — 3.3 V from main board (default)
J23	3–4 ON	VDD_HV_PMU— 3.3 V from main board (default)
J16	Choose one: 2–4 ON 3–4 ON	VDD_LV_CORE — use NPN transistor, internal regulation VDD_LV_CORE — 1.25 V from main board, external regulation (default)

4.1.2 Option 2: Power from external supply

This configuration allows the EVB to operate in standalone configuration using external power supplies, as shown in [Figure 3](#). Power to the EVB is supplied via the terminal block J4 as shown in [Table 4](#). The core supply can be externally regulated or internally regulated using the NPN transistor.




Figure 3. Power from external supplies

[Table 3](#) shows the switch settings when power is sourced externally via the terminal block.

Table 3. Switch settings — power from external supply

Jumper	Setting	Description
J1	4–6 ON	VDD_HV_IO — 3.3 V from external supply
J3	4–6 ON	VDD_HV_FLA0 — 3.3 V from external supply
J19	4–6 ON	VDD_HV_OSC0 — 3.3 V from external supply
J20	Choose one: 6–8 ON 8–10 ON	VDD_HV_ADR0 — 3.3 V from external supply VDD_HV_ADR0 — 5 V from external supply
J21	Choose one: 6–8 ON 8–10 ON	VDD_HV_ADR1 — 3.3 V from external supply VDD_HV_ADR1 — 5 V from external supply
J22	4–6 ON	VDD_HV_ADV0/1 — 3.3 V from external supply
J23	4–6 ON	VDD_HV_PMU — 3.3 V from external supply
J16	Choose one: 2–4 ON 4–6 ON	VDD_LV_CORE — use NPN transistor, internal regulation VDD_LV_CORE — 1.25 V from external supply, external regulation

Table 4. External power input

J4	Description
Pin 1	1.25 V
Pin 2	3.3 V
Pin 3	5 V
Pin 4	GND

4.1.3 Option 3: Power from PwrSBC

This configuration allows the EVB to operate standalone, using the MC33907 PwrSBC device on the EVB as shown in Figure 4. The PwrSBC is a multi-output power supply with built-in CAN and LIN transceivers. It generates the 5 V and 3.3 V power to the MCU. In this configuration, the core supply is regulated internally using the NPN transistor. Power to the EVB is supplied via the 2.1 mm power connector (P2).

Table 5 shows the switch settings when power is sourced from the PwrSBC.




Figure 4. Power from the PwrSBC

Table 5. Switch settings — power from PwrSBC

Jumper	Setting	Description
J1	2–4 ON	VDD_HV_IO — 3.3 V from PwrSBC
J3	2–4 ON	VDD_HV_FLA0 — 3.3 V from PwrSBC
J19	2–4 ON	VDD_HV_OSC0 — 3.3 V from PwrSBC
J20	2–4 ON	VDD_HV_ADR0 — from PwrSBC, see J24
J21	2–4 ON	VDD_HV_ADR1 — from PwrSBC, see J24
J24	Choose one: 2–4 ON 1–3 ON	VDD_HV_ADR0 and VDD_HV_ADR1 — 3.3 V from PwrSBC (default) VDD_HV_ADR0 and VDD_HV_ADR1 — 5 V from PwrSBC
J22	Choose one: 2–4 ON	VDD_HV_ADV0/1 — 3.3 V from PwrSBC
J23	Choose one: 2–4 ON	VDD_HV_PMU — 3.3 V from PwrSBC
J16	2–4 ON	VDD_LV_CORE — use NPN transistor, internal regulation

4.2 VPP_TEST

The VPP_TEST switch (J6) must be pulled low to allow Debug mode to be entered.

Table 6. Switch settings —VPP_TEST

J6	Description
Choose one: 1–2 ON 2–3 ON	Pull VPP_TEST high Pull VPP_TEST low (default)

4.3 Boot configuration

Table 7 shows the J7 switch settings to configure the boot configuration. When booting from UART or CAN, connect the expansion board to the main board and use the interface connectors described below.

Table 7. Switch settings — Boot configuration

J7	Description	
1–2 ON 3–4 ON 5–6 ON	FAB:ABS2:ABS1 = 000 (default)	Normal boot
1–2 OFF 3–4 ON 5–6 ON	FAB:ABS2:ABS1 = 100	Boot from UART Connect expansion board to main board. Use main board RS-232 connector J19.
1–2 OFF 3–4 ON 5–6 OFF	FAB:ABS2:ABS1 = 10	Boot from CAN Connect expansion board to main board. Use main board CAN connector J5.

4.4 Clocks

The EVB provides the following options for clock sources:

- Default: 40 MHz crystal (Y200)
- 8 MHz crystal oscillator (Y201)
- External clock input via SMA connector (J11)

The default clock source is the 40 MHz crystal. Changing the clock source to the 8 MHz crystal oscillator or the external clock input requires removing and replacing resistors, as shown in Table 8.

Figure 8 shows the bottom-side view of the EVB and the location of each of the relevant resistors.

Table 8. Clock source configuration

Clock Source	Configuration
40 MHz crystal	0 Ω resistors R234 and R235 are installed (default).
8 MHz oscillator	Remove 0 Ω resistors R234 and R235. Install 0 Ω resistor to R238 and R233. Remove jumper J12 pins 1–2 to enable the output.

Table 8. Clock source configuration (continued)

Clock Source	Configuration
External clock	Remove 0 Ω resistors R234 and R235. Install 0 Ω resistors to R239 and R233. Install 50 Ω resistor to R236.

Table 9 shows the configuration to enable the 8 MHz oscillator.

Table 9. 8 MHz oscillator output enable/disable

J12	Description
1–2 ON	8 MHz oscillator output disabled (default)
1–2 OFF	8 MHz oscillator output enabled

4.5 I/O connectivity

Some of the MCU's I/Os are routed to the main board and the PwrSBC.

4.5.1 DSPI0 connectivity

Jumper J18 allows the DSPI0 signals to be routed to the main board or to the PwrSBC.

When the expansion board is powered by the main board, J18 should be configured to connect the DSPI0 signals to the main board. The DSPI0 signals can be accessed on the main board from the port pin connectors as shown in Table 25.

When the expansion board is powered by the PwrSBC, J18 should be configured to connect the DSPI0 signals to the PwrSBC to allow communication between the MCU and the PwrSBC via SPI.

Table 10 shows the J18 switch settings.

Table 10. Switch settings — DSPI and ADC0 connectivity

J18	Description
Choose one: 1–2 ON 2–6 ON	DSPI0 SOUT connectivity Connect DSPI0 SOUT (PC6) to PwrSBC Connect DSPI0 SOUT (PC6) to main board (default)
Choose one: 4–5 ON 5–3 ON	DSPI0 SIN connectivity Connect DSPI0 SIN (PC7) to PwrSBC Connect DSPI0 SIN (PC7) to main board (default)
Choose one: 7–8 ON 8–9 ON	DSPI0 SCK connectivity Connect DSPI0 SCK (PC5) to PwrSBC Connect DSPI0 SCK (PC5) to main board (default)
Choose one: 10–11 ON 11–12 ON	DSPI0 CS0 connectivity Connect DSPI0 CS0 (PC4) to PwrSBC Connect DSPI0 CS0 (PC4) to main board (default)

4.5.2 FlexCAN_0 connectivity

Jumper J17 allows the FlexCAN_0 TXD/RXD (PB0/PB1) signals to be routed to the main board or to the PwrSBC.

When the EVB is powered by the main board, J17 should be configured to connect to the CAN interface of the main board. The FlexCAN_0 signals are connected to the main board CAN transceiver that is accessed via the J5 DB9 connector on the main board. The FlexCAN_0 signals can be accessed on the main board from the port pin connectors as shown in [Table 25](#).

When the EVB is powered by the PwrSBC, J17 should be configured to connect the FlexCAN_0 TXD/RXD (PB0/PB1) signals to the PwrSBC as shown in [Table 11](#). The PwrSBC's built-in CAN transceiver connects to the J8 DB9 interface connector on the expansion board.

[Table 11](#) shows the switch settings for J17. Note the jumper settings for J17 require diagonal connections, in other words, pins 1–5 instead of pins 1–2.

Table 11. Switch settings — CAN0 and LIN0 connectivity

J17	Description
Choose one: 2–4 ON	FlexCAN0_TXD Connectivity Connect FlexCAN_0 TXD (PB0) to PwrSBC. Use J8 DB9 connector on the expansion board.
2–6 ON	Connect FlexCAN_0 TXD (PB0) to main board. Use J5 DB9 connector on main board. (default)
Choose one: 5–1 ON	FlexCAN0_RXD Connectivity Connect FlexCAN_0 RXD (PB1) to PwrSBC. Use J8 DB9 connector on the expansion board.
5–3 ON	Connect FlexCAN_0 RXD (PB1) to main board. Use J5 DB9 connector on main board. (default)
Choose one: 8–10 ON	LINFlexD_0 TXD Connectivity Connect LINFlexD_0 TXD (PB2) to PwrSBC. Use J15 Molex connector on the expansion board.
8–12 ON	Connect LINFlexD_0 TXD (PB2) to main board. Use J19 DB9 connector on the main board. (default)
Choose one: 11–7 ON	LINFlexD_0 RXD Connectivity Connect LINFlexD_0 RXD (PB3) to PwrSBC. Use J15 Molex connector on the expansion board.
11–9 ON	Connect LINFlexD_0 RXD (PB3) to main board. Use J19 DB9 connector on the main board. (default)

4.5.3 LINFlexD_0 connectivity

Jumper J17 allows the LINFlexD_0 TXD/RXD (PB2/PB3) signals to be routed to the main board or the PwrSBC.

When the EVB is powered by the main board, J17 should be configured to connect to the LIN interface on the main board. The LINFlexD_0 signals are connected to the main board eSCI/RS-232 transceiver that is accessed via the J19 DB9 connector on the main board. The LINFlexD_0 signals can be accessed on the main board from the port pin connectors as shown in [Table 25](#).

When the EVB is powered by the PwrSBC, J17 should be configured to connect the LINFlexD_0 signals to the PwrSBC as shown in [Table 11](#). The PwrSBC's built-in LIN transceiver connects to the J16 Molex connector on the expansion board.

[Table 11](#) shows the switch settings for J17. Note the jumper settings for J17 require diagonal connections, in other words, pins 1–5 instead of pins 1–2.

4.5.4 FlexCAN_1 connectivity

The FlexCAN_1 TXD/RXD (PA14/PA15) signals are routed to the main board via the interface connectors. The FlexCAN_1 signals are connected to the main board CAN transceiver that is accessed via the J6 DB9 connector on the main board.

4.5.5 LINFlexD_1 connectivity

The LINFlexD_1 TXD/RXD (PF14/PF15) signals are routed to the main board via the interface connectors. The LINFlexD_1 signals are connected to the main board LIN transceiver that is accessed via the J4 Molex connector on the main board. The LINFlexD_1 signals can be accessed on the main board from the port pin connectors as shown in [Table 25](#).

4.5.6 FlexRay_A connectivity

The FlexRay_A TX/RX/TXEN (PD3/PD2/PD4) signals are routed to the main board via the interface connectors. The FlexRay_A signals are connected to the main board FlexRay transceiver that is accessed via the J2 DB9 connector on the main board.

4.5.7 FlexRay_B connectivity

The FlexRay_B TX/RX/TXEN (PD0/PD1/PC15) signals are routed to the main board via the interface connectors. The FlexRay_B signals are connected to the main board FlexRay transceiver that is accessed via the J2 DB9 connector on the main board.

4.6 Main board I/O power

Jumper J13 on the EVB selects between 3.3 V and 5 V for power to the main board transceivers. The main board transceivers are powered by VDD_HV_IO_MAIN. The default power to VDD_HV_IO_MAIN is 3.3 V.

Table 12. Switch settings — main board VDD_HV_IO_MAIN

J13	Description
Choose one: 1–2 ON 2–3 ON	VDD_HV_IO_MAIN is 5 V VDD_HV_IO_MAIN is 3.3 V (default)

4.7 PwrSBC settings

This section includes settings related to the PwrSBC. Jumper settings in this section have no effect when the EVB is powered by the main board or by external supplies. These settings only apply when the EVB is powered by the PwrSBC.

4.7.1 CAN termination

When the CAN interface on the expansion board is used, jumper J9 provides termination resistors to the CANH and CANL pins of the PwrSBC transceiver.

Table 13 shows the J9 switch settings to enable or disable the PwrSBC CAN termination resistors.

Table 13. Switch settings — PwrSBC CAN termination resistors

J9	Description
1-3 ON 1-3 OFF	Enable PwrSBC CANL termination resistor (default) Disable PwrSBC CANL termination resistor
2-4 ON 2-4 OFF	Enable PwrSBC CANH termination resistor (default) Disable PwrSBC CANH termination resistor

4.7.2 LIN master/slave configuration

Table 14 shows the J15 switch settings to configure the PwrSBC LIN interface in master or slave configuration.

Table 14. Switch settings — PwrSBC LIN master/slave configuration

J15	Description
1-2 ON 1-2 OFF	PwrSBC LIN is in master configuration (default) PwrSBC LIN is in slave configuration

4.7.3 NMI_B and RESET_B

Jumper J2 allows the MCU's NMI_B and RESET_B signals to be routed to the PwrSBC. Table 15 shows the J2 switch settings.

Table 15. Switch settings — NMI_B and RESET_B connectivity

J2	Description
1-2 ON 1-2 OFF	Connect NMI_B to PwrSBC. Do not connect NMI_B to PwrSBC (default).
3-4 ON 3-4 OFF	Connect RESET_B to PwrSBC. Do not connect RESET_B to PwrSBC (default).

4.7.4 PwrSBC IO_0:5

Table 16 shows the J10 jumper which allows access to the PwrSBC IO_x pins. The IO_x pins are inputs to the PwrSBC for monitoring various signals.

J10 also provides connection between the FCCU_F[0:1] and PwrSBC IO_2:3 pins to allow the PwrSBC to monitor the status of the MCU's FCCU error output pins.

Table 16. Switch settings — PwrSBC IO_0:5

J10	Description
2	PwrSBC IO_0
4	PwrSBC IO_1
6	PwrSBC IO_2
8	PwrSBC IO_3
10	PwrSBC IO_4
12	PwrSBC IO_5
5–6 ON 5–6 OFF	Connect FCCU_F0 to PwrSBC IO_2. Do not connect FCCU_F0 to PwrSBC IO_2 (default).
7–8 ON 7–8 OFF	Connect FCCU_F1 to PwrSBC IO_3. Do not connect FCCU_F1 to PwrSBC IO_3 (default).

5 Reset switches

The push-button switches (SW1 and SW2) provide external power-on-reset and reset to the MCU. Table 17 shows the reset switches.

Table 17. Reset switches

Switches	Description
SW1	EXT_POR_B for external power-on reset
SW2	RESET_B for functional reset

6 Connectors

Table 18 lists the connectors available on the EVB.

Table 18. Connectors

Connector	Description
P1	38-pin Nexus parallel trace
P2	2.1 mm barrel connector for standalone configuration using PwrSBC
J4	4-pin terminal block for standalone configuration using external power
J5	14-pin JTAG

Table 18. Connectors (continued)

Connector	Description
J8	DB-9 PwrSBC CAN interface
J11	SMA external clock
J14	Molex PwrSBC LIN interface
J200	240-pin main board interface
J201	240-pin main board interface

6.1 JTAG connector

The JTAG port is accessed via the 14-pin BERG connector (J5).

Table 19. JTAG connector

Pin	Signal	Pin	Signal
1	TDI	2	GND
3	TDO	4	GND
5	TCK	6	GND
7	EVTI	8	EXT_POR_B
9	RESET_B	10	TMS
11	VDD_HV_IO	12	GND
13	RDY_B	14	JCOMP

6.2 Nexus parallel trace connector

Nexus parallel trace is supported via the 38-pin MICTOR connector (P1).

Table 20. Nexus parallel trace connector

Pin	Signal	Pin	Signal
1	NC	2	NC
3	NC	4	NC
5	NC	6	NC
7	FAB	8	NC
9	RESET_B	10	EVTI
11	TDO	12	VDD_HV_IO
13	NC	14	RDY_B
15	TCK	16	NC
17	TMS	18	NC
19	TDI	20	NC

Table 20. Nexus parallel trace connector (continued)

Pin	Signal	Pin	Signal
21	JCOMP	22	NC
23	NC	24	MDO3
25	NC	26	MDO2
27	NC	28	MDO1
29	NC	30	MDO0
31	12V	32	EVTO_B
33	12V	34	MCKO
35	NC	36	MSEO1_B
37	NC	38	MSEO0_B

6.3 Main board interface

The two high-density interface connectors on the expansion board (J201 and J200) card allow connection to the main board's matching connectors (J56 and J43).

Table 21. Main board interface connector J201

J201A connector				J201B			
Pin	Signal	Pin	Signal	Pin	Signal	Pin	Signal
1	1.25 V	2	1.25 V	121	5 V	122	5 V
3	1.25 V	4	1.25 V	123	5 V	124	5 V
5	PA0	6	PA1	125	NC	126	NC
7	PA2	8	PA3	127	NC	128	NC
9	PA4	10	PA5	129	NC	130	NC
11	PA6	12	PA7	131	NC	132	NC
13	PA8	14	PA9	133	NC	134	NC
15	PA10	16	PA11	135	NC	136	NC
17	PA12	18	PA13	137	NC	138	NC
19	NC	20	NC	139	NC	140	NC
21	NC	22	NC	141	RESET_B	142	NC
23	NC	24	NC	143	NC	144	NC
25	PC0	26	PC1	145	NC	146	NC
27	PC2	28	NC	147	NC	148	NC
29	PC4	30	MB_PTC5	149	NC	150	NC
31	PC6	32	MB_PTC7	151	NC	152	NC
33	MB_CAN_RXD	34	MB_CAN_TXD	153	NC	154	NC

Table 21. Main board interface connector J201 (continued)

J201A connector				J201B			
Pin	Signal	Pin	Signal	Pin	Signal	Pin	Signal
35	PC10	36	PC11	155	NC	156	NC
37	PC12	38	PC13	157	NC	158	NC
39	PC14	40	NC	159	NC	160	NC
41	3.3 V	42	3.3 V	161	1.25 V	162	1.25 V
43	3.3 V	44	3.3 V	163	1.25 V	164	1.25 V
45	NC	46	NC	165	NC	166	NC
47	NC	48	NC	167	NC	168	NC
49	NC	50	PA14	169	NC	170	NC
51	PF15	52	PF14	171	NC	172	NC
53	NC	54	PG8	173	NC	174	NC
55	PG9	56	PG10	175	NC	176	NC
57	PG11	58	NC	177	NC	178	NC
59	NC	60	NC	179	NC	180	NC
61	1.25 V	62	1.25 V	181	5 V	182	5 V
63	1.25 V	64	1.25 V	183	5 V	184	5 V
65	NC	66	NC	185	NC	186	NC
67	PG2	68	PG3	187	NC	188	NC
69	PG4	70	PG5	189	NC	190	NC
71	PG6	72	PG7	191	NC	192	NC
73	NC	74	NC	193	NC	194	NC
75	NC	76	NC	195	NC	196	NC
77	NC	78	NC	197	NC	198	NC
79	PA15	80	NC	199	NC	200	NC
81	NC	82	NC	201	3.3 V	202	3.3 V
83	NC	84	NC	203	3.3 V	204	3.3 V
85	NC	86	NC	205	NC	206	NC
87	NC	88	NC	207	NC	208	NC
89	NC	90	NC	209	NC	210	NC
91	NC	92	NC	211	NC	212	NC
93	NC	94	NC	213	NC	214	NC
95	NC	96	NC	215	NC	216	NC
97	NC	98	NC	217	NC	218	NC
99	NC	100	NC	219	NC	220	NC

Table 21. Main board interface connector J201 (continued)

J201A connector				J201B			
Pin	Signal	Pin	Signal	Pin	Signal	Pin	Signal
101	NC	102	NC	221	VDD_HV_IO_MAIN	222	VDD_HV_IO_MAIN
103	NC	104	NC	223	VDD_HV_IO_MAIN	224	VDD_HV_IO_MAIN
105	PE0	106	NC	225	NC	226	NC
107	PE2	108	NC	227	NC	228	NC
109	PE4	110	PE5	229	NC	230	NC
111	PE6	112	PE7	231	NC	232	NC
113	NC	114	PE9	233	NC	234	NC
115	PE10	116	PE11	235	NC	236	NC
117	PE12	118	PE13	237	NC	238	NC
119	PE14	120	PE15	239	NC	240	NC

Table 22. Main board interface connector J200

J201A connector				J201B			
Pin	Signal	Pin	Signal	Pin	Signal	Pin	Signal
120	5 V	119	5 V	240	1.25 V	239	1.25 V
118	5 V	117	5 V	238	1.25 V	237	1.25 V
116	NC	115	NC	236	PB7	235	PB8
114	NC	113	NC	234	PB13	233	PB14
112	NC	111	NC	232	PB9	231	PB10
110	NC	109	NC	230	PB5	229	PB4
108	NC	107	NC	228	PB11	227	PB6
106	NC	105	NC	226	PB15	225	PB12
104	NC	103	NC	224	NC	223	NC
102	NC	101	NC	222	NC	221	NC
100	NC	99	NC	220	5 V	219	5 V
98	NC	97	NC	218	5 V	217	5 V
96	NC	95	NC	216	NC	215	NC
94	NC	93	NC	214	NC	213	NC
92	NC	91	NC	212	NC	211	PD5
90	NC	89	NC	210	PD6	209	PD7
88	NC	87	NC	208	PD8	207	PD9
86	NC	85	NC	206	PD10	205	PD11

Table 22. Main board interface connector J200 (continued)

J201A connector				J201B			
Pin	Signal	Pin	Signal	Pin	Signal	Pin	Signal
84	NC	83	NC	204	PD12	203	NC
82	NC	81	NC	202	MB_LIN_TXD	201	MB_LIN_RXD
80	1.25 V	79	1.25 V	200	3.3 V	199	3.3 V
78	1.25 V	77	1.25 V	198	3.3 V	197	3.3 V
76	NC	75	NC	196	PF0	195	NC
74	NC	73	NC	194	NC	193	PF3
72	NC	71	NC	192	PF4	191	PF5
70	NC	69	NC	190	PF6	189	PF7
68	NC	67	NC	188	PF8	187	PF9
66	NC	65	NC	186	PF10	185	PF11
64	NC	63	NC	184	PF12	183	PF13
62	NC	61	NC	182	NC	181	NC
60	NC	59	NC	180	1.25	179	1.25
58	NC	57	NC	178	1.25	177	1.25
56	NC	55	NC	176	PD14	175	NC
54	NC	53	NC	174	NC	173	PD3
52	NC	51	NC	172	PD4	171	NC
50	NC	49	NC	170	NC	169	PD0
48	NC	47	NC	168	PC15	167	PD1
46	NC	45	NC	166	PD2	165	NC
44	NC	43	NC	164	NC	163	NC
42	NC	41	NC	162	NC	161	NC
40	3.3 V	39	3.3 V	160	3.3 V	159	3.3 V
38	3.3 V	37	3.3 V	158	3.3 V	157	3.3 V
36	NC	35	NC	156	NC	155	NC
34	NC	33	NC	154	NC	153	NC
32	NC	31	NC	152	NC	151	NC
30	NC	29	NC	150	NC	149	NC
28	NC	27	NC	148	PJ8	147	PJ9
26	NC	25	NC	146	NC	145	NC
24	NC	23	NC	144	NC	143	NC
22	NC	21	NC	142	NC	141	NC
20	VDD_HV_IO_MAIN	19	VDD_HV_IO_MAIN	140	NC	139	NC

Table 22. Main board interface connector J200 (continued)

J201A connector				J201B			
Pin	Signal	Pin	Signal	Pin	Signal	Pin	Signal
18	VDD_HV_IO_MAIN	17	VDD_HV_IO_MAIN	138	NC	137	NC
16	NC	15	NC	136	NC	135	NC
14	NC	13	NC	134	NC	133	NC
12	NC	11	NC	132	NC	131	NC
10	NC	9	NC	130	NC	129	NC
8	NC	7	NC	128	NC	127	NC
6	NC	5	NC	126	NC	125	NC
4	NC	3	NC	124	NC	123	NC
2	NC	1	NC	122	NC	121	NC

7 LEDs

LEDs shown in [Table 23](#) provide indicators for:

- Power from externally-supplied voltages
- Power output from the PwrSBC
- Reset states
- Fail-safe signals from the PwrSBC

Table 23. LEDs

LED	Description
D1	PwrSBC FS0
D2	EXT_POR_B
D3	RESET_B
D4	External power supply 5 V
D5	External power supply 3.3 V
D6	External power supply 1.25 V
D7	PwrSBC VSUP
D10	PwrSBC VCAN
D12	PwrSBC FS1
D15	PwrSBC VAUX
D16	PwrSBC VCCA
D17	PwrSBC VCORE
D18	PwrSBC VPRE

8 Test points

Test points shown in [Table 24](#) are available to allow probing of various voltages.

Table 24. Test points

Test Point	Description
TP1	VDD_HV_FLA0
TP2	GND
TP3	GND
TP4	VSUP3 — PwrSBC supply
TP5	VDD_HV_IO
TP6	VDD_HV_OSC0
TP7	GND
TP8	VCAN — PwrSBC VCAN output
TP9	FS1 — PwrSBC fail-safe output 1
TP10	VSUP1/2 — PwrSBC supply
TP11	VSW1/VSW2 — PwrSBC switching point
TP12	VDD_LV_PLL
TP13	VDD_LV_CORE
TP14	FB_CORE — PwrSBC feedback core
TP16	COMP_CORE — PwrSBC compensation
TP17	VSW_CORE PwrSBC switching core
TP18	VPRE — PwrSBC preregulator
TP19	VDD_HV_ADR0
TP20	VDD_HV_ADR1
TP21	VDD_HV_ADV0/1
TP22	VDD_HV_PMU
TP23	VAUX — PwrSBC VAUX output
TP24	VCCA — PwrSBC VCCA output
TP25	VCORE — PwrSBC VCORE output
TP26	CLK_OUT

9 Port pin to main board mapping

When the expansion board is connected to the main board, the port pins are routed to the main board via the interface connectors. [Table 25](#) shows the port pin mapping to the main board connectors.

For example, port pin PB4 can be accessed on the main board from connector P9 pin 8.

Table 25. Port pin mapping to main board connectors

MPC5744P port pin	MPC5746MMB port pin connectors	MPC5746MMB communication interface
PA0	P8.1	
PA1	P8.2	
PA2	P8.3	
PA3	P8.4	
PA4	P8.5	
PA5	P8.6	
PA6	P8.7	
PA7	P8.8	
PA8	P8.9	
PA9	P8.10	
PA10	P8.11	
PA11	P8.12	
PA12	P8.13	
PA13	P8.14	
PA14	P12.6	J6 CAN DB9 connector
PA15	P14.15	
PB0	P10.10 (Must connect J17 2–6 on expansion board)	J5 CAN DB9 connector
PB1	P10.9 (Must connect J17 5–3 on expansion board)	
PB2	P11.15 (Must connect J17 8–12 on expansion board)	J19 RS-232 DB9 connector
PB3	P11.16 (Must connect J17 9–11 on expansion board)	
PB4	P9.8	
PB5	P9.7	
PB6	P9.10	
PB7	P9.1	
PB8	P9.2	
PB9	P9.5	
PB10	P9.6	
PB11	P9.9	
PB12	P9.12	
PB13	P9.3	
PB14	P9.4	

Table 25. Port pin mapping to main board connectors (continued)

MPC5744P port pin	MPC5746MMB port pin connectors	MPC5746MMB communication interface
PB15	P9.11	
PC0	P10.1	
PC1	P10.2	
PC2	P10.3	
PC3	Not implemented	
PC4	P10.5 (Must connect J18 11–12 on expansion board)	
PC5	P10.6 (Must connect J18 8–9 on expansion board)	
PC6	P10.7 (Must connect J18 2–3 on expansion board)	
PC7	P10.8 (Must connect J18 5–6 on expansion board)	
PC8	Not implemented	
PC9	Not implemented	
PC10	P10.11	
PC11	P10.12	
PC12	P10.13	
PC13	P10.14	
PC14	P10.15	
PC15	P15.9	J2 FlexRay DB9 connector
PD0	P15.8	
PD1	P15.10	
PD2	P15.11	J2 FlexRay DB9 connector
PD3	P15.4	
PD4	P15.5	
PD5	P11.6	
PD6	P11.7	
PD7	P11.8	
PD8	P11.9	
PD9	P11.10	
PD10	P11.11	
PD11	P11.12	
PD12	P11.13	
PD13	Not implemented	
PD14	P15.1	
PD15	Not implemented	


Table 25. Port pin mapping to main board connectors (continued)

MPC5744P port pin	MPC5746MMB port pin connectors	MPC5746MMB communication interface
PE0	P18.1	
PE1	P18.2	
PE2	P18.3	
PE3	P18.4	
PE4	P18.5	
PE5	P18.6	
PE6	P18.7	
PE7	P18.8	
PE8	P18.9	
PE9	P18.10	
PE10	P18.11	
PE11	P18.12	
PE12	P18.13	
PE13	P18.14	
PE14	P18.15	
PE15	P18.16	
PF0	P13.1	
PF1	Not implemented	
PF2	Not implemented	
PF3	P13.4	
PF4	P13.5	
PF5	P13.6	
PF6	P13.7	
PF7	P13.8	
PF8	P13.9	
PF9	P13.10	
PF10	P13.11	
PF11	P13.12	
PF12	P13.13	
PF13	P13.14	
PF14	P12.8	J4 LIN Molex connector
PF15	P12.7	
PG0	Not implemented	
PG1	Not implemented	

Table 25. Port pin mapping to main board connectors (continued)


MPC5744P port pin	MPC5746MMB port pin connectors	MPC5746MMB communication interface
PG2	P14.3	
PG3	P14.4	
PG4	P14.5	
PG5	P14.6	
PG6	P14.7	
PG7	P14.8	
PG8	P12.10	
PG9	P12.11	
PG10	P12.12	
PG11	P12.13	
PG12	Not implemented	
PG13	Not implemented	
PG14	Not implemented	
PG15	Not implemented	
PJ0	Not implemented	
PJ1	Not implemented	
PJ2	Not implemented	
PJ3	Not implemented	
PJ4	Not implemented	
PJ5	Not implemented	
PJ6	Not implemented	
PJ7	Not implemented	
PJ8	P17.9	
PJ9	P17.10	
PJ10	Not implemented	
PJ11	Not implemented	
PJ12	Not implemented	
PJ13	Not implemented	
PJ14	Not implemented	
PJ15	Not implemented	

10 Diagrams




FREESCALE 5501 WILLIAM CANNON DRIVE WEST AUSTIN, TEXAS 78735 USA		NAME MPC5744-144DC	
THIS DOCUMENT CONTAINS INFORMATION PROPRIETARY TO FREESCALE AND SHALL NOT BE USED FOR ENGINEERING DESIGN PROCUREMENT OR MANUFACTURE IN WHOLE OR IN PART WITHOUT THE CONSENT OF FREESCALE.		--- PUBJ (PUBLIC INFORMATION) -X- FIUG (FREESCALE INTERNAL USE ONLY) --- FCP (FREESCALE CONFIDENTIAL PROPRIETARY)	
SHEET 2 OF 12	FLM PRIMARY SILKSCREEN	DATE 06-17-12	NUMBER 170-27513 REV A

Figure 5. Jumpers, connectors, and switches



FREESCALE 6501 WILLIAM CANNON DRIVE WEST AUSTIN, TEXAS 78736 USA		NAME MPC5744-144DC
THIS DOCUMENT CONTAINS INFORMATION PROPRIETARY TO FREESCALE AND SHALL NOT BE USED FOR ENGINEERING DESIGN PROCUREMENT OR MANUFACTURE IN WHOLE OR IN PART WITHOUT THE CONSENT OF FREESCALE.		--- PUBI (PUBLIC INFORMATION) --- FIUQ (FREESCALE INTERNAL USE ONLY) --- FCP (FREESCALE CONFIDENTIAL PROPRIETARY)
SHEET 2 OF 12	FILE PRIMARY SILKSCREEN	DATE 06-17-12
		NUMBER 170-27513
		REV A

Figure 7. Test points



REV A	DATE	NUMBER	170-5213
3 OF 17	SECONDARY SILSCREEN	02-15-12	
SHEET OR IN PART WITHOUT THE CONSENT OF FREESCALE. FCP (FREESCALE CONFIDENTIAL PROPRIETARY) PROPRIETARY TO FREESCALE AND SHALL NOT BE USED FOR ENGINEERING DESIGN PURPOSES OR MANUFACTURE IN WHOLE OR IN PART WITHOUT THE CONSENT OF FREESCALE.			
THIS DOCUMENT CONTAINS INFORMATION PROPRIETARY TO FREESCALE AND SHALL NOT BE USED FOR ENGINEERING DESIGN PURPOSES OR MANUFACTURE IN WHOLE OR IN PART WITHOUT THE CONSENT OF FREESCALE.			
800 WILLIAM CANNON DRIVE WEST FREESCALE AUSTIN, TEXAS 78758 USA			
NAME MPC5744-144DC			

Figure 8. Bottom view

11 Revision history

Table 26. Revision history

Revision number	Date	Description
0	08/2012	Initial version.
1	11/2012	Correct values in table 10, “Switch settings — DSPI and ADC0 connectivity,” and in table 25, “Port pin mapping to main board connectors.”