



## TEP0001 CAN FD TRM

**Authors:** Jan Kumann  
**Revision:** V21  
**Date:** 09-Dec-2016 18:23

# Table of Contents

---

Overview	3
Features	3
Main Components	3
Interfaces and Pins	4
J1 Connector, CAN0 Bus	4
J2 Connector, Pmod Interface	4
J3 Connector, CAN0 Bus	4
J4 Connector, CAN1 Bus	4
J5 Jumper Block/Connector CAN1 bus	5
J6 Jumper Block/Connector, CAN0 bus	5
Operating Conditions, Ratings and Dimensions	6
Recommended Operating Conditions	6
Absolute Maximum Ratings	6
Power Requirements	6
Physical Dimensions	6
Revision History	7
Hardware Revision History	7
Document Change History	7
Disclaimer	8
Document Warranty	8
Limitation of Liability	8
Copyright Notice	8
Technology Licenses	8
Environmental protection	8
REACH	9
RoHS	9
WEEE	9

## Overview


Refer to [https://shop.trenz-electronic.de/de/Download/?path=Trenz\\_Electronic/PMOD/TEP0001](https://shop.trenz-electronic.de/de/Download/?path=Trenz_Electronic/PMOD/TEP0001) for online version of this manual and other documents available about the product.

The Trenz Electronic TEP0001 is an industrial-grade dual CAN FD transceiver with Pmod interface.


## Features

- Diligent Pmod interface compatible
- Dual CAN FD PHY's (CAN0 and CAN1)
  - Texas Instruments TCAN337G
  - Up to 5Mbit data rate
  - Compatible with ISO 11898-2
  - Bus pin fault protection of  $\pm 14$  V
  - Integrated 12 kV IEC-61000-4-2 ESD contact discharge protection
  - 10 pin headers (IDC cable to DB9)
  - One CAN FD transceiver has extra 3-pin screw connector terminal
- Single 3.3V supply

## Main Components



- J1. Screw connector terminal of CAN0 bus
- J2. 2.54mm pitch 2x6-pin header Pmod interface
- J3. 2.54mm pitch 2x5-pin box header, CAN0 bus
- J4. 2.54mm pitch 2x5-pin box header, CAN1 bus
- J5. 2.54mm pitch SMT 2x3-pin jumper block, can also be used as CAN1 bus connector
- J6. 2.54mm pitch SMT 2x3-pin jumper block, can also be used as CAN0 bus connector
- U1. Texas Instruments TCAN337G CAN FD transceiver, CAN0
- D1. Bourns CDSOT23-T24CAN CANbus Protector, CAN0
- U2. Texas Instruments TCAN337G CAN FD transceiver, CAN1
- D2. Bourns CDSOT23-T24CAN CANbus Protector, CAN1

 TEP0001 PMOD connector is mounted for Right Angle connection to PMOD Baseboard.

## Interfaces and Pins

---

### J1 Connector, CAN0 Bus

---

Pin	Signal	Notes
1	CAN0_H	U1 high level CAN bus line
2	GND	U1 ground connection
3	CAN0_L	U1 low level CAN bus line

### J2 Connector, Pmod Interface

---

Pin	Signal	Notes	Pin	Signal	Notes
1	CAN0_TX	U1 CAN0 transmit data input, integrated pull up	2	CAN1_TX	U2 CAN1 transmit data input, integrated pull up
3	CAN0_RX	U1 CAN0 receive data output, tri-state	4	CAN1_RX	U2 CAN1 receive data output, tri-state
5	CAN0_S	U1 silent mode, integrated pull down	6	CAN1_S	U2 silent mode, integrated pull down
7	CAN0_F	U1 open drain fault output	8	CAN1_F	U2 open drain fault output
9	GND	U1 ground connection	10	GND	U2 ground connection
11	3.3V	U1 3.3V supply voltage	12	3.3V	U2 3.3V supply voltage

### J3 Connector, CAN0 Bus

---

Pin	Signal	Notes	Pin	Signal	Notes
1	N/A	-	2	GND	U1 ground connection
3	CAN0_L	U1 low level CAN bus line	4	CAN0_H	U1 high level CAN bus line
5	GND	U1 ground connection	6	N/A	-
7	N/A	-	8	N/A	-
9	N/A	-	10	N/A	-

### J4 Connector, CAN1 Bus

---

Pin	Signal	Notes	Pin	Signal	Notes
1	N/A	-	2	GND	U2 ground connection
3	CAN1_L	U2 low level CAN bus line	4	CAN1_H	U2 high level CAN bus line
5	GND	U2 ground connection	6	N/A	-
7	N/A	-	8	N/A	-

Pin	Signal	Notes	Pin	Signal	Notes
9	N/A	-	10	N/A	-

## J5 Jumper Block/Connector CAN1 bus

---

Close pins 1-3 and 2-4 with jumpers to enable on-board terminator for CAN1 bus. J5 header can also be used as CAN1 bus connector, refer to the following table pin mapping.

Pin	Signal	Note	Pin	Signal	Note
3	CAN1_L	U2 low level CAN bus line	4	CAN1_H	U2 high level CAN bus line
5	GND	U2 ground connection	6	GND	U2 ground connection

## J6 Jumper Block/Connector, CAN0 bus

---

Close pins 1-3 and 2-4 with jumpers to enable on-board terminator for CAN0 bus. J6 header can also be used as CAN0 bus connector, refer to the following table for pin mapping.

Pin	Signal	Note	Pin	Signal	Note
3	CAN0_L	U1 low level CAN bus line	4	CAN0_H	U1 high level CAN bus line
5	GND	U1 ground connection	6	GND	U1 ground connection

# Operating Conditions, Ratings and Dimensions

---

## Recommended Operating Conditions


---

	Minimum	Maximum	Unit
Supply voltage	3	3.6	V
Operational free-air temperature	-40	125	°C

## Absolute Maximum Ratings

---

Parameter	Minimum	Maximum	Unit
Supply voltage range	-0.3	5	V
Voltage at any bus terminal (CANH or CANL)	-14	14	V
Operating temperature range	-40	150	°C
Storage temperature	-	150	°C

 Refer to Texas Instruments [TCAN337G](#) product datasheet for additional information about conditions and ratings.

## Power Requirements

---

3.3V supply voltage TBD\* (180 mA max per one CAN FD transceiver in "Normal Mode", dominant state with bus fault as per TCAN337G datasheet).

\* TBD - To Be Determined soon with reference design setup.

## Physical Dimensions

---

- Module size: 54 mm x 20.5 mm.
- Mating height of the J2 connector from the PCB: 8mm
- PCB thickness: 1.6mm
- Highest parts on PCB are J1, J3 and J4 connectors, approximately 9.5mm from the PCB.

# Revision History

---

## Hardware Revision History

---

Date	Revision	Notes	PCN
2016-08-22	01	Initial batch	-

Hardware revision number is printed on the PCB board next to the module model number separated by the dash.



## Document Change History

---

Date	Rrevision	Contributors	Description
2016-09-05	V21	Jan Kumann	Initial document.

# Disclaimer

---

## Document Warranty

---

The material contained in this document is provided “as is” and is subject to being changed at any time without notice. Trenz Electronic does not warrant the accuracy and completeness of the materials in this document. Further, to the maximum extent permitted by applicable law, Trenz Electronic disclaims all warranties, either express or implied, with regard to this document and any information contained herein, including but not limited to the implied warranties of merchantability, fitness for a particular purpose or non infringement of intellectual property. Trenz Electronic shall not be liable for errors or for incidental or consequential damages in connection with the furnishing, use, or performance of this document or of any information contained herein.

## Limitation of Liability

---

In no event will Trenz Electronic, its suppliers, or other third parties mentioned in this document be liable for any damages whatsoever (including, without limitation, those resulting from lost profits, lost data or business interruption) arising out of the use, inability to use, or the results of use of this document, any documents linked to this document, or the materials or information contained at any or all such documents. If your use of the materials or information from this document results in the need for servicing, repair or correction of equipment or data, you assume all costs thereof.

## Copyright Notice

---

No part of this manual may be reproduced in any form or by any means (including electronic storage and retrieval or translation into a foreign language) without prior agreement and written consent from Trenz Electronic.

## Technology Licenses

---

The hardware / firmware / software described in this document are furnished under a license and may be used /modified / copied only in accordance with the terms of such license.

## Environmental protection

---

To confront directly with the responsibility toward the environment, the global community and eventually also oneself. Such a resolution should be integral part not only of everybody's life. Also enterprises shall be conscious of their social responsibility and contribute to the preservation of our common living space. That is why Trenz Electronic invests in the protection of our Environment.