# RTE Series — Analog Timers

**Timers** 

## **Key features:**

- 20 time ranges and 10 timing functions
- Time delays up to 600 hours
- Space-saving package
- High repeat accuracy of ± 0.2%
- ON and timing OUT LED indicators
- Standard 8- or 11-pin and 11-blade termination
- 2 form C delayed output contacts
- 10A Contact Rating



Cert. No. E9950913332316 (EMC, RTE) Cert. No. BL960813332355 (LVD, RTE)







# Contact Ratings

	•	
Contact	Configuration	2 Form C, DPDT (Delay output)
	le Voltage / le Current	240V AC, 30V DC / 10A
	m Permissible ng Frequency	1800 cycles per hour
	Resistive	10A 240V AC, 30V DC
Rated	Inductive	7A 240V AC, 30V DC
Load	Horse Power Rating	1/6 HP 120V AC, 1/3 HP 240V AC
132-	Electrical	500,000 op. minimum (Resistive)
Life	Mechanical	50,000,000 op. minimum

# **General Specifications**

Operation System         Solid state CMOS Circuit           Operation Type         Multi-Mode           Time Range         0.1sec to 600 hours           Pollution Degree         2 (IE60664-1)           Over voltage category         III (IE60664-1)           AF20         100-240V AC(50/60Hz)					
Time Range         0.1sec to 600 hours           Pollution Degree         2 (IE60664-1)           Over voltage category         III (IE60664-1)           AF20         100-240V AC(50/60Hz)					
Pollution Degree         2 (IE60664-1)           Over voltage category         III (IE60664-1)           AF20         100-240V AC(50/60Hz)					
Over voltage category         III (IE60664-1)           AF20         100-240V AC(50/60Hz)					
AF20 100-240V AC(50/60Hz)					
B					
Rated Operational Voltage AD24 24V AC(50/60Hz)/24V DC					
D12 12V DC					
AF20 85-264V AC(50/60Hz)					
Voltage Tolerance AD24 20.4-26.4V AC(50/60Hz)/21.6-26.4V DC					
D12 10.8-13.2V DC					
Input off Voltage Rated Voltage x10% minimum					
Ambient Operating Temperature -20 to +65°C (without freezing)					
Ambient Storage and Transport Temperature -30 to +75°C (without freezing)					
Relative Humidity 35 to 85%RH (without condensation)					
Atmospheric Pressure 80kPa to 110kPa (Operating), 70kPa to 110k	)kPa (Transport)				
Reset Time 100msec maximum					
Repeat Error ±0.2%, ±20msec*	±0.2%, ±20msec*				
Voltage Error ±0.2%, ±20msec*					
Temperature Error ±0.5%, ±20msec*					
Setting Error ±10% maximum					
Insulation Resistance 100MΩ minimum (500V DC)					
Between power and output terminals: 2000	JOV AC, 1 minute				
Dielectric Strength Between contacts of different poles: 2000V					
Between contacts of the same pole:1000V	/ AC, 1 minute				
Vibration Resistance 10 to 55Hz amplitude 0.5mm² hours in each					
Operating extremes: 98m/sec <sup>2</sup> (10G)					
Shock Resistance Damage limits: 490m/sec <sup>2</sup> (50G)					
3 times in each of 3 axes					
Degree of Protection IP40 (enclosure) (IEC60529)					
TYPE RTE-P1, -B1 R	RTE-P2, -B2				
	6.6VA				
Power Consumption AF20 240V AC/60Hz 11.6VA 1	11.6VA				
(Approx.) 24V AC 60Hz/DC 3.4VA/1.7W 3	3.5VA/1.7W				
	1.6W				
Mounting Position Free					
RTE-P1, P2 40Hx 36W x 77.9D mm					
Dimensions         RTE-B1, B2         40Hx 36W x 74.9D mm					
RTE-P1 RTE-P2 R	RTE-B1, -B2				
Weight (Approx.) 87g 89g 8	85g				




\*For the value of the error against a preset time, whichever the largest, applies.



**www.IDEC.com** 1705151136

# **Part Numbering Guide**

RTE series part numbers are composed of 4 part number codes. When ordering a RTE series part, select one code from each category. Example: **RTE-P1AF20** 



## **Part Numbers: RTE Series**

	Description	Part Number Code	Remarks
① Series	RTE series	RTE	For internal circuits, see next page.
(2) Tarminal Ctula	Pin	Р	Colort and only
② Terminal Style	Blade	В	Select one only.
	ON-delay, interval, cycle OFF, cycle ON	1	Each function group has different timing functions.
③ Function Group	ON-delay, cycle OFF, cycle ON, signal ON/ OFF delay, OFF-delay, one-shot	2	See page 940.
	100 to 240V AC(50/60Hz)	AF20	
① Input Voltage	24V AC(50/60Hz)/24V DC	AD24	
	12V DC	D12	

## **Part Numbers**

Voltage	Power T	riggered	Start Input Triggered			
voitage	8-Pin	Blade	11-Pin	Blade		
12V DC	RTE-P1D12	RTE-B1D12	RTE-P2D12	RTE-B2D12		
24V AC/DC	RTE-P1AD24	RTE-B1AD24	RTE-P2AD24	RTE-B2AD24		
100-240V AC	RTE-P1AF20	RTE-B1AF20	RTE-P2AF20	RTE-B2AF20		


# **Time Range Determined by Time Range Selector and Dial Selector**


	Dial	0 - 1	0 - 3	0 - 10	0 - 30	0 - 60
	Second	0.1 sec - 1 sec	0.1 sec - 3 sec	0.2 sec - 10 sec	0.6 sec - 30 sec	1.2 sec - 60 sec
ıge	Minute	1.2 sec - 1 min	3.6 sec - 3 min	12 sec - 10 min	36 sec - 30 min	1.2 min - 60 min
Ranç	Hour	1.2 min - 1 hr	3.6 min - 3 hr	12 min - 10 hr	36 min - 30 hr	1.2 hr - 60 hr
	10 Hours	12 min - 10 hr	36 min - 30 hr	2 hr - 100 hr	6 hr - 300 hr	12 hr - 600 hr

# **Timing Diagrams**

**Timers** 

## RTE-P1, -B1







1. RTE-B1: Do not apply voltage to terminals #2, #5 & #8.

 IDEC sockets are as follows: RTE-P1: SR2P-06\* pin type socket, RTE-B1: SR3B-05\* blade type socket, (\*-may be followed by suffix letter A,B,C or U).

### A: ON-Delay 1 (power start)

Set timer for desired delay, apply power to coil. Contacts transfer after preset time has elapsed, and remain in transferred position until timer is reset. Reset occurs with removal of power.

Item	Terminal Nu	mber		Operati	ion	
Power	(1) 2 - 7 (2) A - B					
Delayed	(1) 1 - 4, 5 - 8 (2) 1 - 7, 3 - 9	(NC)				
Contact	(1) 1 - 3, 6 - 8 (2) 4 - 7, 6 - 9	(NO)				
Indicator	PWR					
indicator	OUT					
Set Time			4	T		

#### C: Cycle 1 (power start, OFF first)

Set timer for desired delay, apply power to coil. First transfer of contacts occurs after preset delay has elapsed, after the next elapse of preset delay contacts return to original position. The timer now cycles between on and off as long as power is applied (duty ratio 1:1).

Item	Terminal Nu	nber	Operation							
Power	(1) 2 - 7 (2) A - B									
Delayed	(1) 1 - 4, 5 - 8 (2) 1 - 7, 3 - 9	(NC)								
Contact	(1) 1 - 3, 6 - 8 (2) 4 - 7, 6 - 9	(NO)								
ladianta.	PWR									
Indicator	OUT									
Set Time				<b>←</b>						

### B: Interval (power start)

Set timer for desired delay, apply power to coil. Contacts transfer immediately, and return to original position after preset time has elapsed. Reset occurs with removal of power.

Item	Terminal Nur	nber		Operati	ion	
Power	(1) 2 - 7 (2) A - B					
Delayed	(1) 1 - 4, 5 - 8 (2) 1 - 7, 3 - 9	(NC)				
Contact	(1) 1 - 3, 6 - 8 (2) 4 - 7, 6 - 9	(NO)				
Indicator	PWR					
indicator	OUT					
Set Time			4	т -		

#### D: Cycle 3 (power start, ON first)


Functions in same manner as Mode C, with the exception that first transfer of contacts occurs as soon as power is applies. The ratio is 1:1. Time  $On = Time\ Off$ 

Item	Terminal Nu	mber			Op	eration		
Power	(1) 2 - 7 (2) A - B							
Delayed	(1) 1 - 4, 5 - 8 (2) 1 - 7, 3 - 9	(NC)						
Contact	(1) 1 - 3, 6 - 8 (2) 4 - 7, 6 - 9	(NO)						
Indicator	PWR							
muicator	OUT							
Set Time			<b>←</b>	<b>←</b>				



## Timing Diagrams con't

### RTE-P2, -B2



### A: ON-Delay 2 (signal start)

When a preset time has elapsed after the start input turned on while power is on, the NO output contact goes on.

Item	Terminal Nur	nber	Operat	tion	
Power	(A) 2 - 10 (B) A - B				
Start	(A) 5 - 6 (B) 2 - 5				
Delayed	(A) 1 - 4, 8 - 11 (B) 1 - 7, 3 - 9	(NC)			
Contact	(A) 1 - 3, 9 - 11 (B) 4 - 7, 6 - 9	(NO)			
Indicator	PWR				
indicator	OUT				
Set Time			- T	-	


#### C: Cycle 4 (signal start, ON first)

When the start input turns on while power is on, the NO contact goes on. The output oscillates at a preset cycle (duty ratio 1:1).

Item	Terminal Nur	nber					Operat	tion					
Power	(A) 2 - 10 (B) A - B												
Start	(A) 5 - 6 (B) 2 - 5												
Delayed	(A) 1 - 4, 8 - 11 (B) 1 - 7, 3 - 9	(NC)											
Contact	(A) 1 - 3, 9 - 11 (B) 4 - 7, 6 - 9	(NO)											
Indicator	PWR												
indicator	OUT												
Set Time				-	+	-	-	-	-	-	-	4+	
Set IIIIe				Т	Т	Т	Т	Т	Т	Т	Т	Ta	

### E: Signal OFF-Delay

When power is turned on while the start input is on, the NO output contact goes on. When a preset time has elapsed after the start input turned off, the NO output contact goes off.




# A

- 1. RTE-P2: Do not apply voltage to terminals #5, #6 & #7.
- 2. RTE-B2: Do not apply voltage to terminals #2, #5 & #8.
- IDEC sockets are as follows: RTE-P2: SR3P-05\* pin type socket, RTE-B2: SR3B-05\* blade type socket, (\*-may be followed by suffix letter A,B,C or U).


### B: Cycle 2 (signal start, OFF first)

When the start input turns on while power is on, the output oscillates at a preset cycle (duty ratio 1:1), starting while the NO contact off.



#### D: Signal ON/OFF-Delay

When the start input turns on while power is on, the NO output contact goes on. When a preset time has elapsed while the start input remains on, the output contact goes off. When the start input turns off, the NO contact goes on again. When a preset time has elapsed after the start input turned off, the NO contact goes off.



### F: One-Shot (signal start)


When the start input turns on while power is on, the NO output contact goes on. When a preset time has elapsed, the NO output contact goes off.

Item	Terminal Nur	nber		Oper	ation		
Power	(A) 2 - 10 (B) A - B						
Start	(A) 5 - 6 (B) 2 - 5						
Delayed	(A) 1 - 4, 8 - 11 (B) 1 - 7, 3 - 9	(NC)					
Contact	(A) 1 - 3, 9 - 11 (B) 4 - 7, 6 - 9	(NO)					
Indicator	PWR						
maicator	OUT						
Set Time							


948


# **Temperature Derating Curves**

Timers




Mounting B






### Instructions

#### Installation of Hold-Down Springs DIN Rail Mount Socket





## **Switch Settings**



- @Operator Mode Selector
- ©Scale Selector
- Time Range Selector
- Turn the selectors securely using a flat screwdriver 4mm wide (maximum).
   Note that incorrect setting may cause malfunction. Do not turn the selectors beyond their limits.
- Since changing the setting during timer operation may cause malfunction, turn power off before changing.

## **Safety Precautions**

Special expertise is required to use Electronic Timers.

- All Electronic Timers are manufactured under IDEC's rigorous quality control system, but users must add a backup or fail safe provision to the control system when using the Electronic Timer in applications where heavy damage or personal injury may occur should the Electronic Timer fail.
- Install the Electronic Timer according to instructions described in this catalog.
- Make sure that the operating conditions are as described in the specifications. If you are uncertain about the specifications, contact IDEC in advance.
- In these directions, safety precautions are categorized in order of importance under Warning and Caution.

## Warnings

Warning notices are used to emphasize that improper operation may cause severe personal injury or death.

- Turn power off to the Electronic timer before starting installation, removal, wiring, maintenance, and inspection on the Electronic Timer.
- · Failure to turn power off may cause electrical shocks or fire hazard.

 Do not use the Electronic Timer for an emergency stop circuit or interlocking circuit. If the Electronic Timer should fail, a machine malfunction, breakdown, or accident may occur.

### **Caution**

Caution notices are used where inattention might cause personal injury or damage to equipment.

- The Electronic Timer is designed for installation in equipment. Do not install the Electronic Timer outside equipment.
- Install the Electronic Timer in environments described in the specifications. If
  the Electronic Timer is used in places where it will be subjected to high-temperature, high-humidity, condensation, corrosive gases, excessive vibrations,
  or excessive shocks, then electrical shocks, fire hazard, or malfunction could
  result.
- Use an IEC60127-approved fuse and circuit breaker on the power and output line outside the Electronic Timer.
- Do not disassemble, repair, or modify the Electronic Timer.
- When disposing of the Electronic Timer, do so as industrial waste.



# **Accessories**

## **DIN Rail Mounting Accessories**

# **DIN Rail/Surface Mount Sockets and Hold-Down Springs**

	DIN Rail Mount Socket	Applicable Hold-Down Springs			
Style	Appearance	Use with Timers	Part Number	Appearance	Part Number
11-Pin Screw Terminal (dual tier)		- RTE-P2	SR3P-05		SFA-203
11-Pin FingerSafe Socket			SR3P-05C		
8-Pin Screw Terminal		RTE-P1	SR2P-06	Car Ol Call	SFA-202
8-Pin Fingersafe Socket			SR2P-05C		
11-Blade Screw Terminal		RTE-B1 RTE-B2	SR3B-05		
DIN Mounting Rail Length 1000mm		_	BNDN1000		

# **Panel Mounting Accessories**

## Flush Panel Mount Adapter and Sockets that use an Adapter

Accessory	Description	Appearance	Use with	Part No.
Panel Mount Adapter	Adaptor for flush panel mounting RTE timers		All RTE timers	RTB-G01
Sockets for use with Panel Mount Adapter	8-pin screw terminal		RTE-P1	SR6P-M08G
	11-pin screw terminal	(Shown: SR6P-M08G Wiring Socket Adapter)	RTE-P2	SR6P-M11G
	8-pin solder terminal		RTE-P1	SR6P-S08
	11-pin solder terminal		RTE-P2	SR6P-S11