



TRB SERIES PAD / PARALLELING / T ADAPTER

TRB SERIES PAD TRB 3-LUG PLUG AND JACK




BN73 Shown




TRB "T" ADAPTER	3-lug	BN73
	2-lug	BN73TL
TRT "T" ADAPTER	4-lug	BN73FL
	Threaded	BN373

PART NUMBER CIRCUITRY SCHEMATIC


TNG2-R




TNG2A-R1-R2




TNG3-R




TNG3A-R1-R2



TNG4-R1-R2-R3




TNG4A-R1-R2-R3-R4-R5-R6




R-Resistance (1/2 W 1%)
Substitute resistive value for each "R_N" unless all values are identical.

FIXED PARALLELING JACKS

TN2A Shown



TN2 Shown



FIXED PARALLELING JACK

Two Plugs, One Jack	3-lug	TN2
	2-lug	TN2TL
	4-lug	TN2FL
	Threaded	TN2T
Two Jacks, One Plug	3-lug	TN2A
	2-lug	TN2TLA
	4-lug	TN2FLA
	Threaded	TN2TA

* Other options available including Random Paralleling.
Contact the factory for more information.

For Adapters, see pages 47-50. For Terminations, see page 45-46. For Impedance Matching Adapters, see page 47.