

Motor Control Application Kit

KITMOTORDC250W24VTOBO1

3-phase Motor Control Power Card

24V, 250W motor drive power card for XMC1000 and XMC4000

User Manual

About this document

Scope and purpose

This document describes in technical details the implementation and use of a 3-phase motor drive power card. The card has been designed to operate in various configurations and coditions, such input voltages and control algorithms.

The hardware is compatible with XMC DriveCards and DAVE™ configurations.

Attention: This board is intended for evaluation purposes only and is not intended to be an end product.

The design of this board originates from the need of a simple and plug-and-play motor drive power card to be used for XMC evaluation purposes in motor drive applications.

The layout of the board has been studied to offer a good starting reference to designers.

Intended audience

Design engineers approaching a low-voltage motor drive system either in H-Bridge or in 3-Phase full bridge configuration.

1 Table of Contents

| 2 | 1 | Introduction2 |
|---|---|-----------------------|
| 3 | 2 | Block diagram |
| 4 | 3 | Hardware description4 |



Introduction

1 1 Introduction

This document describes the features and hardware details of the "3-phase motor control Power Card" which
 is designed to work with Infineon's DriveCards. DriveCards are microcontroller boards with isolated debug

- 4 interface best suited for motor control applications. This power board works with DriveCards
- 5 KIT_XMC1300_DC_V1 and KIT_XMC4400_DC_V1.
- 6
- 7 The "3-phase motor control Power Card" is designed to work under several supply voltage levels which are
- 8 described in TABLEXX. A first buck converter produces the regulated 12V supply for the MOSFETs gate
- 9 driving and a second buck converter generates the regulated 5V supply for the microcontroller and the
 10 analog signal conditioning.
- 11 The 3-phase bridge is composed by three Half-Bridges with SO8 gate driver IC and SSO8 power MOSFETs.
- 12 Each leg provides a shunt resistor with amplifier for reconstruction of the phase current. A DC-link shunt is
- also provided. With the provided shunts configuration, the board provides flexibility to adopt many different
- 14 control algorithms.



Block diagram

1 2 Block diagram

- 2 Figure 1 Shows a simplified block diagram of the hardware, which includes:
- 3 3-phase motor drive bridge, equipped with 6x BSC014N06N from OptiMOS™ 8oV family, 1.4mOhm (max)
 4 power MOSFETs in SSO8 package
- Half-Bridge gate driver IC 2EDLo5No6PF from EICEDriver™ COMPACT family in SO8 package with SOI technology
- SwitchedMode DC/DC buck converter IFX90121EL V50 for 5V supply
- 8 SwitchedMode DC/DC buck converter for 12V supply
- 9 Shunts to sense leg currents and DC-link current, with OpAmps for conditioning to XMC
- 10 Resistor dividers to sense leg voltages and DC-link voltage, to XMC
- Additional general purpose Green-LED (EN, Enable port), 5V Green-LED and 12V Green-LED
- Additional general purpose trimmer to XMC



14 Figure 1 Simplified block diagram

User Manual

2

Hardware description



1 3 Hardware description

The following sections give a detailed description of the hardware and how it can be used.



5 Figure 2 Hardware TOP overview

6 Table 1 Ratings

| Description | Max | Тур | Notes |
|-----------------------|-------------------|-----|--|
| DC link input voltage | 6oV absolute max | 24V | Hardware can run from 16V up to 42V operating |
| Output Power | TBD | | No heatsink, still air, Ambient temperature, Test conditions TBD |
| Power mosfet ratings | 6oV BVDss abs max | | BSCo14No6N 1.4mOhm Rdson Max |
| SMPS IC rating | 6oV BVDss abs max | | |
| | | | |

7 3.1.1 Signal connector

8 The signal connector pin-out is listed below in Table 2. See also Figure 3 for reference.

| User Manual | |
|-------------|--|
|-------------|--|

Hardware description



1 Table 2 Signal connector pin-out

| Row A | Name | Notes | Row B | Name | Notes |
|-------------|---------------|--------------------------|-------------|---------------|------------------------------|
| (inner row) | | | (outer row) | | |
| CN4-A16 | GND | Ground | CN4-B16 | VDD_5V | XMC supply |
| CN4-A15 | | | CN4-B15 | | |
| CN4-A14 | RVAR | Variable res | CN4-B14 | TEMP | Temperature sense |
| CN4-A13 | | | CN4-B13 | DC_LINK_DIV_X | Voltage sense DC link |
| CN4-A12 | I_U | Current sense U | CN4-B12 | BEMF_U | Voltage sense phase U |
| CN4-A11 | I_V | Current sense V | CN4-B11 | BEMF_V | Voltage sense phase V |
| CN4-A10 | I_W | Current sense W | CN4-B10 | BEMF_W | Voltage sense phase W |
| CN4-A9 | I_DC_LINK_AVG | Current sense DC link | CN4-B9 | I_DC_LINK_0 | |
| CN4-A8 | | NC | CN4-B8 | U_L | Phase U low side command |
| CN4-A7 | | NC | CN4-B7 | U_H | Phase U high side command |
| CN4-A6 | | NC | CN4-B6 | V_L | Phase V low side command |
| CN4-A5 | | NC | CN4-B5 | V_H | Phase V high side command |
| CN4-A4 | | NC | CN4-B4 | W_L | Phase W low side command |
| CN4-A3 | | NC | CN4-B3 | W_H | Phase W high side command |
| CN4-A2 | | NC | CN4-B2 | /FO_0 | Fault / NC |
| CN4-A1 | | NC | CN4-B1 | /ENABLE_0 | Driver enable |

User Manual

Hardware description



1



2 Figure 3 Signal DriveCard connector front view with pin-1/row A marked

3 3.1.2 Input Power and motor connectors

- 4 The board can be equipped with a standard low power RAPC 5A connector for demonstation purposes.
- 5 Pinout is providing also standard 2-pin 5mm spacing drills for higher power Voltage connection.



```
6 Figure 4 Jack Connector polarity
```

User Manual





1



2 Figure 5 Power Drivecard connector view

3 Motor connections are available in the 3-pin power connector shown on the right side of Figure 5.

4 3.1.3 3-phase bridge

5 The 3-phase MOSFET bridge in Figure 6 shows MOSFETs, gate resistors and shunts.

6 The U₃ comparator for overcurrent DC-link protection is also shown, providing a active-low FO (Fault) sigal to

7 the microcontroller via XMC DriveCard signal connector.

8 Current trip is set by the resistor divider R20/R21 following Eq. 1.

$$V_{TH} = 2.5V \cdot \frac{R21}{R21 + R20} = 2.5V \cdot \frac{10K}{10K + 40K} = 0.5V$$

$$I_{TRIP} = \frac{V_{TH}}{R_{SHUNT}} = \frac{0.5V}{0.02 \ Ohm} = 25A$$
Eq. 1

9 A single-pole filter (represented by R19, C27) is added to trim noise immunity.

10 Values are R19=1KOhm, C27=1nF.

User Manual

Hardware description





2 Figure 6 3-phase MOSFET bridge

- Shunt voltages are fed into the DriveCard signal connector at I_U, I_V, I_W, I_DC_LINK_o pins as shown in
 Table 2.
- 5 Signal amplifiers are set as follows for emitter-shunt sensing (refer to Figure 7, I_U, I_V, I_W signals):

$$Gain_I U = \frac{I_U}{Imotor} = 12 \cdot R_{s1} = \frac{[V]}{[A]}$$

$$Offset_I U = VREF_{2.5V} = 2.5V$$
Eq. 2

6 While for Bus-shunt sensing (refer to Figure 8, I_DC_LINK_o signal):

$$Gain = \frac{I_U}{Imotor} = 12 \cdot R_{s4} / / R_{s4} = \frac{[V]}{[A]}$$

$$Offset = VREF_{2.5V} = 2.5V$$
Eq. 3

7 I_DC_LINL_AVG, averaged version of the I_DC_LINK_o, is available as well at connector.



User Manual

Hardware description





1

Figure 7 Emitter-shunt current amplifier (U phase shown)





4 Figure 8 DC Bus current sensing

5 3.1.4 DC bus Voltage sensing

- 6 DCbus (DC_LINK) voltage is available at DC_LINK_DIV_X, CN4-B13 connector pin.
- 7 Voltage at pin is clamped to 5V1.
- 8 Resistor divider is set to:
- 9 R45=5.6k; R43=56k

DC_LINK_DIV_X =
$$DCbus \cdot \frac{R45}{R45 + R43}$$

@24V Bus voltage: DC_LINK_DIV_X = $24V \cdot \frac{5.6k0hm}{5.6k0hm + 56k0hm} = 2.18V$
@42V Bus voltage: DC_LINK_DIV_X = $42V \cdot \frac{5.6k0hm}{5.6k0hm + 56k0hm} = 3.81V$

nfineon

User Manual



Hardware description





DC bus sensing divider 3 Figure 9

Phase voltage sensing 3.1.5 4

Phase voltage sensing is available at BEMF_U, BEMF_V, BEMF_W pins of the signal connector as mentioned 5 6 in Table 2.

$$BEMF_U = U \cdot \frac{R54}{R54 + R51}$$
 Eq. 5

7 Phase voltage sensing is available for sensorless BLDC scalar control using 6-step modulation scheme as well as for various other scopes. 8

9 Pin voltage is clamped by a 5.1V Zener to protect the uC pin.

Consider that the Zener diode might have considerable capacitive behavior and it might be needed to remove 10 11 12 them from the board.



Figure 10 Phase voltage sensing divider 13

DC/DC converters 3.1.6 14

- The present board embeds two step-down converters. 15
- 16 The first one brings BCbus voltage down to 12V and it is shown in Figure 11.
- The second one brings the supply to the uC and analog circuits from 12V to 5V (Figure 12). 17
- 18

User Manual



Hardware description







Figure 11 Step-down converter from DCbus to 12V

3



4 Figure 12 Step-down converter from 12V to 5V

5 3.1.7 Miscellaneous

Two GREEN ligh LEDs indicate presence of 12V and 5V supply. They both must be turned on when board is
 operative.

8

One LED connected to /ENABLE_o pin of the signal connector is available as general purpose indicator for the
 uController. See Figure 13.

11

User Manual

Hardware description



1



Figure 13 **ENABLE** general purpose LED 2

3 A general purpose MANUAL Trimmer is also available on the board, connected to RVAR (see Table 2).

4 5 RV1 is a 10KOhm trimmer, which ranges from oV to VREF=5V.



6 7

8

NTC thermistor is available as well, with the temperature dependence shown in Figure 14:



10

9

User Manual



Hardware description

1 NTC thermistor is located as shown in Figure 15



2 Figure 15 Position of the NTC thermistor

3 Therimistor capability to sense real mosfet temperature is very limited. It can be used just to have a superficial

4 indication of local PCB temperature.

5 3.1.8 PWM signals

- 6 This board uses as gate driver IC the Compact series EiceDriver™ 2EDLo5No6PF. For detailed specification,
- 7 please visit <u>www.infineon.com/EiceDriver</u> and look for Isolated Gate Driver ICs.
- 8 The main characteristics of the Gate Driver IC follow:
- 9
- Technology: Rugged SOI (Silicon on Isolator) technology, allows negative voltage spikes at VB pin
- Outoput: +360/-700mA gate drive output current capability
- Protection: Interlocking function with minimum deadtime insertion (typ 75ns)
- UVLO: Mosfet tailored Under Voltage Lock Out (rising 9.1V, falling 8.3V typ), suitable for 12V driving voltage
- Bootstrap: Low Ohminc Integrated bootstrap diode
- 16
- 17 In order to drive correctly the mosfet stage, please follow the suggested parameter choice:

18Table 3Motor Control configuration

| Parameter | Value | Units |
|------------------------------|----------------------------------|-------|
| Deadtime | >500 | ns |
| Switch delay time | 400 | ns |
| Polarity | Active high all PWMs | |
| Amplifier gain | 12 | V/V |
| DCLink Voltage divider ratio | 0.909 or 9.09% | |
| Enable pin is DEACTIVATED | Active high \rightarrow Led ON | |

- 19
- 20
- 21
- 22 [1] A Reference. See the code examples at www.infineon.com