



# mQ to BNC/N



## mQ JACK to BNC PLUG

PART NUMBER **R 191 411**



## mQ PLUG to BNC JACK


PART NUMBER **R 191 413**



## mQ JACK TO BNC JACK


Panel sealed, bulkhead feedthrough

PART NUMBER **R 191 416**



## mQ PLUG to N JACK

PART NUMBER **R 191 603**



## mQ JACK to N PLUG

PART NUMBER **R 191 606**

