

PAGE 1/8

ISSUE 06-11-2014


SERIES SPnT

PART NUMBER R594 XXX XXX

SPnT Coaxial Switches DC to 6 GHz, DC to 20 GHz, DC to 26.5 GHz, DC to 40 GHz

Radiall's PLATINUM SERIES switches are optimised to perform at a high level over an extended life span. With outstanding RF performances, and a guaranteed Insertion Loss repeatability of 0.03 dB over a life span of 10 million switching cycles. PLATINUM SERIES switches are perfect for automated test and measurement equipment, as well as signal monitoring devices.

PART NUMBER SELECTION



(1) Connector SMA2.9 is equivalent to "K Connector®", registered trademark of Anritsu

PICTURE





Technical Data Sheet

TERMINATED MULTIPORT SWITCHES PLATINUM Series

PAGE **2/8**

ISSUE 06-11-2014


SERIES SPnT

PART NUMBER R594 XXX XXX

RF PERFORMANCES

PART NUMBER	R5943-34-7 R5943-36-7	R5944-34-7 R5944-36-7	R594F-34-7 R594F-36-7	R5948-34-7 R5948-36-7
Frequency Range GHz	DC to 6	DC to 20	DC to 26.5	DC to 40
Impedance Ohms	50			
Insertion Loss dB (Maximum)	0.3 + 0.015 x frequency (GHz)			
Isolation dB (Minimum)	100	DC to 6 GHz : 100 6 to 12.4 GHz : 90 12.4 to 20 GHz : 80	DC to 6 GHz : 100 6 to 12.4 GHz : 90 12.4 to 20 GHz : 80 20 to 26.5 GHz : 70	DC to 6 GHz : 100 6 to 12.4 GHz : 90 12.4 to 20 GHz : 80 20 to 26.5 GHz : 70 26.5 to 40 GHz : 60
V.S.W.R. (Maximum)	1.20	DC to 6 GHz : 1.20 6 to 12.4 GHz : 1.35 12.4 to 18 GHz : 1.45 18 to 20 GHz : 1.70	DC to 6 GHz : 1.20 6 to 12.4 GHz : 1.35 12.4 to 18 GHz : 1.45 18 to 26.5 GHz : 1.70	DC to 6 GHz : 1.20 6 to 12.4 GHz : 1.35 12.4 to 18 GHz : 1.45 18 to 26.5 GHz : 1.70 26.5 to 40 GHz : 1.90
Third order Inter Modulation	-120 dBc typical (2 carriers 20W)			
Repeatability (measured at 25°C)	0.03 dB			0.05 dB

TYPICAL RF PERFORMANCES





Technical Data Sheet

TERMINATED MULTIPORT SWITCHES PLATINUM Series

PAGE 3/8	
-----------------	--

ISSUE 06-11-2014

SERIES SPnT

PART NUMBER R594 XXX XXX

ADDITIONAL SPECIFICATIONS

Operating mode		Latching		
Nominal operating voltage (Vdc) (across operating temperature)		24 (20 / 32)		
Coil resistance (+/-10%) (Ohms)		120		
Nominal operating current at 23°C (mA)		200		
Maximum stand-by current (mA)		50		
Average power		RF path Cold switching : see Power Rating Chart on page 8 Hot switching : 1 Watt CW		
	High Level	3 to 7 V	1.4 mA max at Vcc = Max	
TTL input	Low Level	0 to 0.8 V		
Indicator specifications			capacity : 150 mA resistance : 2.5Ω	
Switching time max (ms)		15		
Life min for	SMA	10 million cycles		
	SMA 2.9	2.5 million cycles		
Connectors		SMA – SMA 2.9		
Actuator terminal		HE10 ribbon receptacle		
Weight max (g)		230		

ENVIRONMENTAL SPECIFICATIONS

Operating temperature range (°C)	-25 to +75	
Storage temperature range (°C)	-55 to +85	
Temperature cycling (MIL-STD-202 , Method 107D , Cond.A) (°C)	-55 to +85 (10 cycles)	
Vibration (MIL STD 202 , Method 204D , Cond.D)	10-2000 Hz , 10g operating	
Shock (MIL STD 202 , Method 213B , Cond.C)	50g / 6 ms , 1/2 sine operating	
Moisture resistance (MIL STD 202 , Method 106E , Cond.E)	65°C, 95% RH, 10 days	
Altitude storage (MIL STD 202 , Method 105C , Cond.B)	50,000 feet (15,240 meters)	
RFI (MIL STD 1344 , Method 3008 or IEC 61726)	55dB at 20GHz	
Magnetic field	< 5.10 ⁻⁵ gauss at 1 meter	



Technical Data Sheet

TERMINATED MULTIPORT SWITCHES PLATINUM Series

PAGE	4/8
------	-----

ISSUE 06-11-2014

SERIES SPnT

PART NUMBER R594 XXX XXX

ELECTRONIC POSITION INDICATORS

The electronic position indicators use photo-MOS transistors which are driven by the mechanical position of the RF paths moving elements. The circuitry consists of a common which can be connected to an output corresponding to selected RF path. If one or several RF paths are closed, the corresponding indicators are connected to the common. The photo-MOS transistors are configured for AC and/or DC operation. The electronic position indicators require the supply (20 to 32 VDC) to be connected to pin 1 and ground connected to pin 15.

	Pin	number	Funct	ion
<		2	Indicator	Common
~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~		4	Indicator	RF path 1
~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~		6	Indicator	RF path 2
~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~		8	Indicator	RF path 3
~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~		10	Indicator	RF path 4
		12	Indicator	RF path 5
		14	Indicator	RF path 6

Ways 1 and 4 are not connected for SP4T switches.



PAGE **5/8**


ISSUE 06-11-2014

SERIES SPnT

PART NUMBER R594 XXX XXX

DRIVING THE SWITCH : Type 4 : without TTL and indicator

Each RF path is driven independently. Each path can be closed or open by applying ground to the corresponding "open" or "close" pin.



Ways 1 and 4 are not connected for SP4T switches.

Standard drive:

• Connect pin 15 to ground.

• Connect pin 1 to supply (+20 VDC to +32 VDC).

• Select desired RF path by applying ground to the corresponding "close" pin (Ex: ground pin 3 to close RF path 1).

• To open desired RF path connect ground to the corresponding "open" pin (Ex: ground pin 4 to open RF path 1).

• To open all RF paths, first ensure that all RF path "close" pins are disconnected from ground. To complete the operation, connect pin 16 to ground.

Make-Before-Break

Make-Before-Break switching can be accomplished by closing the new RF path before opening the previously selected RF path. To complete the operation, close the new RF port. A minimum of 15 ms must be allowed before opening the previously selected RF port.



PAGE 6/8


ISSUE 06-11-2014

SERIES SPnT

PART NUMBER R594 XXX XXX

DRIVING THE SWITCH : Type 7 : with TTL (option "2") / without TTL (option "1").

Each RF path can be closed by applying Ground or TTL "High" for option 2 to the corresponding "drive" pin. In general, except for Make-Before-Break drive, all other RF paths are simultaneously opened by internal logic.



Ways 1 and 4 are not connected for SP4T switches.

Standard drive option "1"

- Connect pin 15 to ground.
- Connect pin 1 to supply (+20 VDC to +32 VDC)
 Select (close) desired RF path by applying Ground to the corresponding "drive" pin (Ex: apply Ground to

pin 3 to close RF path 1).
To select another path, ensure that all unwanted RF path "drive" pins are disconnected from Ground (to prevent multiple RF path engagement). Apply Ground to the "drive" pin which corresponds to the desired RF path.

• To open all RF paths, ensure that all RF path "drive" pins are disconnected from Ground. Complete the operation by applying Ground to pin 16.

TTL drive option "2"

- Connect pin 15 to ground.
- Connect pin 1 to supply (+20 VDC to +32 VDC)

• Select (close) desired RF path by applying TTL "High " to the corresponding "drive" pin (Ex: apply TTL "High" to pin 3 to close RF path 1).

• To select another path, ensure that all unwanted RF path "drive" pins are in TTL "Low" position (to prevent multiple RF path engagement). Apply TTL "High" to the "drive" pin which corresponds to the desired RF path.

• To open all RF paths, ensure that all RF path "drive" pins are in TTL "Low" position. Complete the operation by applying TTL "High" to pin 16.

Break-Before-Make

Open the undesired RF path. After 15 ms (minimum), close the new RF port.

Make-Before-Break

Ensure that the previously selected RF path "drive" is connected to Ground (or TTL "High" for option "2", then close the new RF path.

