Honeywell

Sensor Evaluation Kit, SEK001

For Use with TruStability™ RSC Series and Digital Output Versions of the HSC Series and SSC Series Board Mount Pressure Sensors

Issue A

Datasheet



DESCRIPTION

The Sensor Evaluation Kit, SEK001, provides an easier way to demonstrate and evaluate Honeywell's TruStability RSC Series, and the digital output versions (I²C or SPI) of the HSC Series and SSC Series Board Mount Pressure Sensors. The kit interfaces a selected sensor to an Arduino[™] Uno Rev3 Microcontroller Board. Honeywell software, which is provided free and is downloadable athttp://sensing.honeywell.com/ sensors/evaluation-kit, controls the Arduino Uno Rev3 to take readings from the sensor. Sensor measurements are displayed on the user's PC and can be recorded to a .csv file for further analysis. In addition to being mounted directly on the SEK001, the sensor may also be remotely connected to the SEK001 via wire leads, allowing the sensor to be tested in adverse environments, or in a prototype product for proof of concept testing.

VALUE TO CUSTOMERS

- Quicker, easier TruStability pressure sensor evaluation: The SEK001 and associated Honeywell software simplify sensor evaluation and demonstration by eliminating the need for the customer to develop any code before seeing sensor measurements.
- Remote mounting: In addition to being mounted on the SEK001, the sensor may also be mounted remotely if, for example, it is to be mounted in an oven for testing or in a prototype product for proof-of-concept testing of the customer's end product.
- Cost-effective: Provides a cost-effective way learn about the capabilities of our sensors so customers can make better informed component decisions faster. Customers are then able to perform a thorough evaluation of the sensor without needing to develop additional code.
- Expedites development: As the SEK001 allows customers to test their product, this helps customers to expedite their development process.

FEATURES

- The SEK001 has sockets to receive TruStability HSC, SSC Series pressure sensors with I²C or SPI digital output, as well as the new TruStability RSC Series high resolution pressure sensors. The board is then plugged in as a shield board to the user-provided Arduino Uno Rev3 board. (All sensors are sold separately. Only one sensor may be evaluated at a time.)
- Five jumpers for an HSC Series or SSC Series, I²C output, 5 Vdc pressure sensor are preconfigured on the board.
- Uses an industry standard Arduino platform
- Sensor Evaluation Boards for other Honeywell sensors are under development

POTENTIAL APPLICATIONS

- Sensor demonstration
- Sensor testing and evaluation
- Proof-of-concept testing

Table 1. Sensor Evaluation Kit Contents and User-Provided Items



Figure 1. SEK001/Arduino Assembly



Table 3. SEK001 Specifications

Characteristic	Parameter		
Temperature range	20°C to 30°C [68°F to 86°F]		
Humidity range	30 %RH to 70 %RH		
Power supply: internal (Arduino) external	3.3 V or 5 V 3.3 V or 5 V		
Compatible sensors	RSC Series HSC Series (digital verions only) SSC Series (digital versions only)		
Associated software	Sensor Evaluation Kit SEK001 Version 1.0.exe Arduino Firmware SEK001 Version 1.0.zip XLoader.zip		



Figure 2. Measurement Screen for HSC, SSC Series Only

Table 4. Measurement Screen Functions for HSC, SSC Series Only

Figure 3. Captured File Clip Sample for HSC, SSC Series Only

Function	Description	
Input Panel:	Selects the desired graph parameters. Click on the "Play" button after making a selection to restart the evaluation.	
Temperature	Displays °C or °F of the sensor's ASIC.	
Pressure	Displays the sensor's pressure.	
#Samples to Avg.	Select from the given number.	
Auto Range	Select to automatically adjust to keep trace on screen.	
Play/Pause	Starts/pauses the LIVE STREAMING function. Also used to restart an evaluation after changing any Input Panel characteristics.	
Record	Records the measurements in a .cvs file in Excel for offline analysis.	
Restart	Resets the time line to 0 sec.	
Snap Shot	Saves a screenshot to a selected folder.	
Saved Snaps Path	Opens the folder of recent file clips and snap shots.	
Captured File Clips	Displays/provides access to recent .cvs files in Excel.	
Part	Displays the part number of the sensor currently being evaluated.	
Serial	Not displayed.	

X	⊠ ,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,				
	ile Home I	nsert Page Layout Formula	s Data Review Vie	ew Acrobat	
1	💐 👗 Cut	Calibri y 11 y /	· · · = = =	wran Text	General
	🔜 🕞 Copy -				e e e
	🗸 🛷 Format Paint	er 🖪 X U * 🖽 * 🧏 *		Merge & Center	5 • % 7
	Clipboard	G Font	G Align	ment	Number
	J1	▼ (° <i>f</i> x			
	A	В	С	D	E
1	Date	04-May-2017 10-09-28			
2	Data Rate (SPS)	5			
3	Part Number	HSCDRRN001ND2A5			
4	Serial Number				
5	TIME (hh:mm:ss)	RAW TEMPERATURE COUNT	RAW PRESSURE COUNT	TEMPERATURE(*C)	PRESSURE (INH2O)
6	0:00:00	820	8320	30.12	0.02
-	0:00:00	820	8320	30.12	0.02
0	0:00:01	820	8320	30.12	0.02
10	0:00:01	820	8320	30.12	0.02
11	0:00:01	820	8317	30.12	0.019
12	0:00:01	820	8320	30.12	0.02
13	0:00:02	820	8322	30.12	0.02
14	0:00:02	820	8320	30.12	0.02
15	0:00:02	820	8320	30.12	0.02
16	0:00:02	820	8320	30.12	0.02
17	0:00:02	820	8317	30.12	0.019
18	0:00:03	820	8322	30.12	0.02
19	0:00:03	820	8322	30.12	0.02
20	0:00:03	820	8320	30.12	0.02
21	0:00:03	820	8320	30.12	0.02
22	0:00:03	820	8322	30.12	0.02
23	0:00:04	820	8320	30.12	0.02
24	0:00:04	820	8322	30.12	0.02
25	0:00:04	820	8322	30.12	0.02
20					
2/					
29					
30					
31					
32					
33					
34					
35					
36					
37					
H	+ ► ► 04May201	7_LOGDATA_1			
Re	ady				



Figure 4. Measurement Screen for RSC Series Only

Table 5. Measurement Screen Functions for RSC Series Only

Function	Description
Input Panel:	Selects the desired graph parameters. Click on the "Play" button after making a selection to restart the evaluation.
VIEW COEFFICIENTS	Displays 12 coefficients, as well as other data (see Figure 10).
Temperature	Displays temperature in °C or °F of the sensor's ASIC.
Pressure	Displays the sensor's pressure.
#Samples to Avg	Select from a given number.
Auto Range	Select to automatically adjust scale to keep trace on screen.
Sensor Data Rate	Select from a given number the rate at which the sensor is programmed to make successive readings.
Play/Pause	Starts/pauses the LIVE STREAMING function. Also used to restart an evaluation after changing any Input Panel characteristics.
Record	Records the measurements in a .cvs file in Excel for offline analysis.
Restart	Resets the time line to 0 sec.
Snap Shot	Saves a screen shot to a selected folder.
Saved Snaps Path	Opens the folder of recent file clips and snap shots.
Captured File Clips	Displays/provides access to recent .cvs files in Excel format.
Part	Displays the part number of the sensor currently being evaluated.
Serial	Displays the serial number of the sensor currently being evaluated.

Figure 5. Captured File Clip Sample for RSC Series Only

	🔚 📝 🔜 🔻 Screen Shots						
F	ile Home Ins	ert Pagelavout Formula	s Data Review	View Acrobat			-
		inter rage cayout i ronnaia		new Acrobat			
	A Cut	Calibri 🕆 11 👻	A* A* 🗮 🚍 😹 🗞 י	Wrap Text	General		Normal
Pa	ste	B I U - 🖂 - 🌆 -		📰 🔤 Merge & Cent	er - \$ - % , .	Conditional	Format Check Cell
	V Format Painter Format Painter Formatting as Table Formatting as Table				s Table *		
	Cipboard 13	ront f	Ally Ally	gnment	Number	12	
_	IVI34	▼ Jx					
	A	В	C	D	F	F	G
1	Date	04-May-2017 10-48-46		TE03: -525555.7	TE02: 15.06208	TE01: 0.002973723	TE00: -3.581009E-07
2	Data Rate (SPS)	5		TES3: 2234052	TES2: -185.6375	TES1: 0.009351089	TES0: -1.918478E-08
3	Part Number	RSCDRRI002NDSE3		PS3: 0.4999541	PS2: 0.997693	PS1: -0.002024277	PS0: 0.008609019
4	Serial Number	201/0680051					
5	TIME (nn:mm:ss)	RAW TEMPERATURE COUNT	RAW PRESSURE COUNT	TEMPERATURE("C)	PRESSURE (INH20 D)		ficients
0	0:00:00	818	-534849	25.5625	-0.044914484	- 0001	ncients
/	0:00:00	818	-535027	25.5025	-0.045254588		
0	0:00:01	010	-534910	25.5025	-0.045042515		
3	0.00.01	010	-354656	25.5025	-0.045008005		
10	0.00.01	010	-52/1920	25.5625	-0.045050144		
12	0:00:01	818	-535030	25.5625	-0.045050144		
13	0:00:02	818	-534997	25.5625	-0.045197248		
14	0:00:02	818	-534921	25.5625	-0.045052052		
15	0:00:02	818	-535041	25,5625	-0.045281291		
16	0:00:02	818	-534841	25,5625	-0.044899106		
17	0:00:02	818	-534918	25.5625	-0.045046329		
18	0:00:03	818	-534887	25.5625	-0.044987082		
19	0:00:03	818	-534806	25.5625	-0.04483223		
20	0:00:03	818	-534982	25.5625	-0.045168638		
21	0:00:03	818	-534851	25.5625	-0.044918299		
22	0:00:03	818	-534866	25.5625	-0.044946909		
23	0:00:04	818	-535008	25.5625	-0.045218229		
24	0:00:04	818	-534921	25.5625	-0.045052052		
25	0:00:04	818	-535062	25.5625	-0.045321465		
26	0:00:04	818	-534939	25.5625	-0.045086384		
27	0:00:04	818	-534936	25.5625	-0.045080662		

Figure 6. View Coefficients Screen for RSC Series Only

EEPROM COEFFICIENTS					
OFFSET COEFFICIENTS					
OffsetCoefficient0	OffsetCoefficient1	OffsetCoefficient2	OffsetCoeffciient3		
-525555.7	15.06208	0.002973723	-3.581009E-07		
SPAN COEFFICIENTS					
SpanCoefficient0	SpanCoefficient1	SpanCoefficient2	SpanCoefficient3		
2234052	-185.6375	0.009351089	-1.918478E-08		
PRESSURE COEFFICIENTS					
ShapeCoefficient0	ShapeCoefficient1	ShapeCoefficient2	ShapeCoefficient3		
0.4999541	0.997693	-0.002024277	0.008609019		

Figure 7. SEK001 Dimensions (For reference only: mm/[in].)



Figure 8. SEK001 Board Layout (Note: The AWM24B set of receiving sockets is not currently used.)



Front (no jumpers shown)