UMFT231XE Version 1.0



Document Reference No.: FT\_000652 Clearance No.: FTDI# 294

## Future Technology Devices International Ltd Datasheet UMFT231XE USB to Full-Handshake UART Development Module



UMFT231XE is a USB to serial Full-Handshake UART DIP module with a 0.6" row pitch.

## 1 Introduction

The UMFT231XE is a development module for FTDI's FT231XQ, one of the devices from FTDI's range of USB interface bridging integrated circuit devices. FT231X is a USB to UART interface with a battery charger detection feature, which can allow batteries to be charged with a higher current from a dedicated charger port (without the FT231X being enumerated). In addition, asynchronous and synchronous bit bang interface modes are available. The internally generated clock (6MHz, 12MHz and 24MHz) can be brought out of the on one of the CBUS pin to be used to drive a microprocessor or external logic.

The UMFT231XE is a module which is designed to plug into a standard 0.6" wide 20 pin DIP socket. All components used, including the FT231XQ are Pb-free (RoHS compliant).

### 1.1 Features

The UMFT231XE is fitted with a FT231XQ, all the features of the FT231X can be utilized with the UMFT231XE. For a full list of the FT231X's features please see the FT231X datasheet which can be found by clicking here.

In addition to the features listed in the FT231X datasheet, the UMFT231XE has the following features:

- Small PCB assembly module designed to fit a standard 15.24mm (0.6") wide 20 pin DIP socket. Pins are on a 2.54mm (0.1") pitch.
- On board USB 'mini-B' socket allows module to be connected to a PC via a standard A to mini-B USB cable.
- Functionally configurable using jumpers. The default jumper setup enables the module to function without peripheral wires or application board. Other configurations enable external power supply options and variation of logic reference levels.



### **Table of Contents**

| 1 | Int                                       | roduction   | L |  |  |  |  |  |
|---|---|---|---|--|--|--|--|--|
|   | 1.1                                       | Features  | 1 |  |  |  |  |  |
| 2 | Dri                                       | ver Support   | 3 |  |  |  |  |  |
| 3 | Orc                                       | dering Information                                  | 3 |  |  |  |  |  |
| 4 | UM  | FT231XE Signals and Configurations                  | 1 |  |  |  |  |  |
|   | 4.1                                       | UMFT231XE Pin Out                                   | 4 |  |  |  |  |  |
|   | 4.2                                       | Signal Descriptions                                 | 5 |  |  |  |  |  |
|   | 4.3                                       | CBUS Signal Options                                 | 5 |  |  |  |  |  |
| 5 | Мо  | dule Configurations                                 | 7 |  |  |  |  |  |
|   | 5.1                                       | Jumper Configuration Options                        | 7 |  |  |  |  |  |
|   | 5.2                                       | Bus Powered Configuration                           | 8 |  |  |  |  |  |
|   | 5.3                                       | Self Powered Configuration                          | 9 |  |  |  |  |  |
|   | 5.4                                       | USB Bus Powered with Power Switching Configuration1 | D |  |  |  |  |  |
|   | 5.5                                       | Variable IO Voltage Supply1                         | 1 |  |  |  |  |  |
|   | 5.6                                       | 3.3V Voltage Supply1                                | 2 |  |  |  |  |  |
|   | 5.7                                       | Configuring the MTP ROM1                            | 2 |  |  |  |  |  |
| 6 | Мо  | dule Dimensions13                                   | 3 |  |  |  |  |  |
| 7 | UM  | FT231XE Module Circuit Schematic14                  | 1 |  |  |  |  |  |
| 8 | Int                                       | Internal MTP ROM Configuration15                    |   |  |  |  |  |  |
| 9 | 9 Contact Information                     |   |   |  |  |  |  |  |
|   | Appendix A - List of Figures and Tables17 |   |   |  |  |  |  |  |
|   | Appendix B – Revision History18           |   |   |  |  |  |  |  |





## 2 Driver Support

# Royalty-Free VIRTUAL COM PORT (VCP) DRIVERS for:

- Windows 7 32,64-bit
- Windows Vista
- Windows XP 32,64-bit
- Windows XP Embedded
- Windows CE.NET 4.2 , 5.0 and 6.0
- MAC OS OS-X
- Linux 3.0 and greater
- Android

# Royalty-Free D2XX Direct Drivers (USB Drivers + DLL S/W Interface):

- Windows 7 32,64-bit
- Windows Vista
- Windows XP 32,64-bit
- Windows XP Embedded
- Windows CE.NET 4.2, 5.0 and 6.0
- MAC OS OS-X
- Linux 3.0 and greater
- Android

The drivers listed above are all available to download for free from <u>www.ftdichip.com</u>. Various 3rd Party Drivers are also available for various other operating systems - visit <u>www.ftdichip.com</u> for details.


## **3 Ordering Information**

| Module Code  | Utilised IC Code | Description   |
|--------------|------------------|---|
| UMFT201XE-01 | FT201XQ          | USB to $I^2C$ evaluation module. 0.6" row pitch, standard DIP headers.              |
| UMFT221XE-01 | FT221XQ          | USB to 8-bit SPI/FT1248 evaluation module. 0.6" row pitch, standard DIP headers.    |
| UMFT231XE-01 | <u>FT231XQ</u>   | USB to Full-Handshake UART evaluation module. 0.6" row pitch, standard DIP headers. |
| UMFT240XE-01 | FT240XQ          | USB to 8-bit 245 FIFO evaluation module. 0.6" row pitch, standard DIP headers.      |



## 4 UMFT231XE Signals and Configurations

### 4.1 UMFT231XE Pin Out



#### Figure 4.1 – Module Pin Out

Figure 4.1 illustrates the signals available on the DIP pins.



## 4.2 Signal Descriptions

| Pin No.       | Name   | Туре                      | Description  |
|---------------|--------|---------------------------|--|
| J1-1,<br>J2-5 | GND    | PWR                       | Module Ground Supply Pins  |
| J1-2          | 3V3OUT | Power<br>Input/<br>Output | 3.3V output from integrated L.D.O. regulator. This pin is decoupled with a 100nF capacitor to ground on the PCB module. The prime purpose of this pin is to provide the 3.3V supply that can be used internally. For power supply configuration details see Section 5.   |
| J1-3          | VCCIO  | Power<br>Input            | +1.8V to +3.3V supply to the UART Interface and CBUS I/O pins. For power supply configuration details see Section 5.   |
| J1-4          | DCD#   | Input                     | Data Carrier Detect Control Input.   |
| J1-5          | DSR#   | Input                     | Data Set Ready Control Input / Handshake Signal.   |
| J1-6          | DTR#   | Output                    | Data Terminal Ready Control Output / Handshake Signal.   |
| J1-7          | CTS#   | Input                     | Clear To Send Control Input / Handshake Signal.  |
| J1-8          | RTS#   | Output                    | Request to Send Control Output / Handshake Signal.   |
| J1-9          | RXD    | Input                     | Receiving Asynchronous Data Input.   |
| J1-10         | TXD    | Output                    | Transmit Asynchronous Data Output.   |
| J2-1          | SLD    | GND                       | USB Cable Shield. Connected to GND via a 0ohm resistor.  |
| J2-2          | VBUS   | Power<br>Output           | 5V Power output from the USB bus. For a low power USB bus powered design, up to 100mA can be sourced from the 5V supply and applied to the USB bus. A maximum of 500mA can be sourced from the USB bus in a high power USB bus powered design. Currents up to 1A can be sourced from a dedicated charger and applied to the USB bus. |
| J2-3          | VCC    | Power<br>Input            | 5V power input for FT231X. For power supply configuration details see Section 5.   |
| J2-4          | RI#    | Input                     | Ring Indicator Control Input. When remote wake up is enabled in the internal MTP ROM taking RI# low >20ms can be used to resume the PC USB host controller from suspend.   |
| J2-6          | RESET# | Input                     | FT231X active low reset line. Configured with an on board pull-up and recommended filter capacitor. When no power is applied to the USB bus reset, will be held low, this prevents current from flowing to the host or hub when in self-powered mode.  |
| J2-7          | CBUS3  | I/O                       | Configurable CBUS I/O Pin. Function of this pin is configured in the device internal MTP ROM. See CBUS Signal Options, Table 4.2.  |
| J2-8          | CBUS2  | I/O                       | Configurable CBUS I/O Pin. Function of this pin is configured in the device internal MTP ROM. See CBUS Signal Options, Table 4.2.  |
| J2-9          | CBUS1  | I/O                       | Configurable CBUS I/O Pin. Function of this pin is configured in the device internal MTP ROM. See CBUS Signal Options, Table 4.2.  |
| J2-10         | CBUS0  | I/O                       | Configurable CBUS I/O Pin. Function of this pin is configured in the device internal MTP ROM. See CBUS Signal Options, Table 4.2.  |

Table 4.1 – Module Pin Out Description



### 4.3 CBUS Signal Options

The following options can be configured on the CBUS I/O pins. These options are all configured in the internal MTP ROM using the utility software FT\_PROG, which can be downloaded from the <u>www.ftdichip.com</u>. The default configuration is described in <u>Section 9</u>.

| CBUS Signal<br>Option | Available On<br>CBUS Pin | Description   |
|-----------------------|--------------------------|---|
| Tristate              | CBUS0-CBUS3              | IO Pad is tri-stated  |
| DRIVE_1               | CBUS0-CBUS3              | Output a constant 1   |
| DRIVE_0               | CBUS0-CBUS3              | Output a constant 0   |
| TXDEN                 | CBUS0-CBUS3              | Enable transmit data for RS485  |
| PWREN#                | CBUS0-CBUS3              | Output is low after the device has been configured by USB, then high during USB suspend mode. This output can be used to control power to external logic P-Channel logic level MOSFET switch.<br><b>NOTE:</b> This function is driven by an open-drain to ground with no internal pull-up, this is specially designed to aid battery charging applications. UMFT231XE connects all CBUS and DBUS signals an on-board 47K pull-up. |
| TXLED#                | CBUS0-CBUS3              | Transmit data LED drive – open drain pulses low when transmitting data via USB.   |
| RXLED#                | CBUS0-CBUS3              | Receive data LED drive – open drain pulses low when receiving data via USB.   |
| TX&RXLED#             | CBUS0-CBUS3              | LED drive – open drain pulses low when transmitting or receiving data via USB.  |
| SLEEP#                | CBUS0-CBUS3              | Goes low during USB suspend mode. Typically used to power down an external logic to RS232 level converter IC in USB to RS232 converter designs. Cancel SLEEP# option for when connected to a dedicated charger port, this can be selected when configuring the MTP ROM. When this option is enabled SLEEP# is driven high when FT231X is connected to a Dedicated Charger Port.   |
| CLK24MHz              | CBUS0-CBUS3              | 24 MHz Clock output.**  |
| CLK12MHz              | CBUS0-CBUS3              | 12 MHz Clock output.**  |
| CLK6MHz               | CBUS0-CBUS3              | 6 MHz Clock output.**   |
| GPIO                  | CBUS0-CBUS3              | CBUS bit bang mode option. Allows up to 4 of the CBUS pins to be used as general purpose I/O. Configured individually for CBUS0, CBUS1, CBUS2 and CBUS3 in the internal MTP ROM. A separate application note, <u>AN232R-01</u> , available from <u>FTDI website (www.ftdichip.com</u> ) describes in more detail how to use CBUS bit bang mode.   |
| BCD_Charger           | CBUS0-CBUS3              | Battery Charge Detect indicates when the device is connected to a dedicated battery charger host. Active high output. NOTE: Requires a 10K pull-down to remove power up toggling.   |
| BCD_Charger#          | CBUS0-CBUS3              | Active low BCD Charger, driven by an open drain to ground with no internal pull-up (4.7K on board pull-up present).   |
| BitBang_WR#           | CBUS0-CBUS3              | Synchronous and asynchronous bit bang mode WR# strobe output.   |
| BitBang_RD#           | CBUS0-CBUS3              | Synchronous and asynchronous bit bang mode RD# strobe output.   |
| VBUS_Sense            | CBUS0-CBUS3              | Input to detect when VBUS is present.   |
| Time_Stamp            | CBUS0-CBUS3              | Toggle signal which changes state each time a USB SOF is received   |
| Keep_Awake#           | CBUSO-CBUS3              | Active Low input, prevents the chip from going into suspend.  |

#### Table 4.2 – CBUS Signal Options

\*\*When in USB suspend mode the outputs clocks are also suspended.



## **5 Module Configurations**

### 5.1 Jumper Configuration Options

| Jumper No. | Setting | Status          | Description  |
|------------|---------|-----------------|--|
| JP1        | Shorted | Default         | Connects internal 3.3V regulator to VCCIO. This restricts signal drive to only 3.3V level signals.   |
| JP1        | Opened  | Non-<br>Default | Disconnects internal 3.3V regulator connection to VCCIO. This mode allows for the supply of 1.8V-3.3V power from an external power supply, thus allows the processing of signals with logic levels between 1.8V and 3.3V. VCCIO can be adjusted to match the interface requirements of external circuitry. |

Table 5.1 – Jumper JP1 Pin Description

| Jumper No. | Setting | Status          | Description  |
|------------|---------|-----------------|--|
| JP2        | Shorted | Default         | Connects VBUS to VCC. This mode is known as "USB-Powered" mode.  |
| JP2        | Opened  | Non-<br>Default | Disconnects VBUS to VCC. This allows the supply of power from an external power supply. This mode is known as "Self-Powered" mode. |

Table 5.2 – Jumper JP2 Pin Description

**Note:** There should never be more than one power output supplied to the same net. If JP2 is fitted when an external power supply is applied a direct short between two power supplies will be formed, this can result in damage to the UMFT231XE module and the target circuit.



### 5.2 Bus Powered Configuration




Figure 5.1 – Bus Powered Configuration

A bus powered configuration draws its power from the USB host/hub. The UMFT231XE is configured by default to be in bus powered mode.

Figure 5.1 illustrates the UMFT231XE module in a typical USB bus powered design configuration. By default VCCIO is connected to 3V3OUT, and VCC is connected to VBUS.

For a bus power configuration power is supplied from the USB VBUS:


+5V VBUS power is sourced from the USB bus and is connected to the FT231X power input (VCC)

+3.3V power is sourced from the FT231X's voltage regulator output and is connected to the FT231X IO port's power input (VCCIO).

Interfacing the UMFT231XE module to a microcontroller (MCU), or other logic devices for bus powered configuration is done the same way as a self-powered configuration (see Section 3), except it is possible for the MCU or external device to take its power supply from the USB bus (either the 5V from the USB pin, or 3.3V from the 3V3OUT pin).



### 5.3 Self Powered Configuration



#### Figure 5.2 – Self-Powered Configuration

A self-powered configuration operates on the principle of drawing power from an external power supply, as oppose to drawing power from the USB host. In this configuration no current is drawn from the USB bus.

Figure 5.2 illustrates the UMFT231XE in a typical USB self-powered configuration. In this case the jumper connection of JP1 is removed, which allows 5V power to be supplied to the module VCC pins from an external source. VCCIO can to be powered from 3V3OUT or the VCC of an external source.


For a self-powered configuration, it is necessary to prevent current from flowing back to the USB data lines when the connected USB host or hub has powered down. To carry out this function the UMFT231XE uses an on-board voltage divider network connected to the USB bus and RESET# pin. This operates on the principle that when no power is supplied to the VBUS line, the FT231X will automatically be held in reset by a weak pull-down, when power is applied the voltage divider will apply a weak 3.3V pull-up. Driving a level to the RESET# pin of the UMFT231XE will override the effect of this voltage divider. When the FT231X is in reset the USB DP signal pull-up resistor connected to the data lines is disconnected and no current can flow down the USB lines.

An example of interfacing the FT231X with a Microcontroller's UART interface is also illustrated in Figure 5.2. This example shows the wire configuration of the transfer and handshake lines. This example also illustrates that a voltage other than 3.3V can be supplied to the FT231X's IO port, this feature is described further and for bus powered mode in Section 5.5.

Alternatively, both the FT231X's IO port and MCU can be powered from the 3V3OUT pin; this approach is described in Section 5.4.



### 5.4 USB Bus Powered with Power Switching Configuration



#### Figure 5.3 – Bus Powered with Power Switching Configuration

USB bus powered mode is introduced in Section 5.2. This section describes how to use bus-powered mode with a power switch.

USB bus powered circuits are required by USB compliance standards to consume less than 2.5mA (and less than 100mA when not enumerated and not suspended) when connected to a host or hub when in USB suspend mode. The PWREN# CBUS function can be used to remove power from external circuitry whenever the FT231X is not enumerated.


To implement a power switch using PWREN#, configure a P-Channel Power MOSFET to have a soft start by fitting a 10K pull-up, a 1K series resistor and a 100nF cap as shown in Figure 5.3.

Connecting the source of the P-Channel MOSFET to 3V3OUT instead of VBUS can allow external logic to source 3.3V power from the FT231X without breaking USB compliancy. In this setup it is important that the VCCIO is not sourced from the drain of this MOSFET, this is because the power used to drive the gate of this transistor is sourced from VCCIO. VCCIO should be connected directly to 3V3OUT for this setup to function effectively. It is also important that the external logic must and IO core of the FT231X must not draw more that 50mA, this is because the current limit of the internal 3.3V regulator is 50mA.



JMFT231XE

### 5.5 Variable IO Voltage Supply



#### Figure 5.4 – USB Bus Powered 3.3V Logic Drive

The FT231X can process signals at CMOS/TTL logic levels in the range of 1.8V to 3.3V. This section describes how to utilise this feature.

Figure 5.4 shows a configuration where the FT231X is interfaced to a device with IOs operating in the range of 1.8V - 3.3V. The IO ports of this module need to be powered with a voltage level that is equal to the level of the signals it is processing. Since the FT231X's embedded voltage regulator only outputs 3V3 the IO ports will need to be powered from another power source when operating at voltage levels other than 3.3V.

By default, a short is present between 3V3OUT (embedded voltage regulator) and VCCIO (IO port's power input with the connection made by JP1. If an external power supply is used to power the IO ports this jumper needs to be open.

The configuration described in this section can be implemented in either bus-powered mode or self-powered mode.


Note 1: The CBUS and DBUS pins are 5V tolerant; however these signals cannot drive signals at 5V TTL/CMOS. VCCIO is not 5V tolerant; applying 5V to VCCIO will damage the chip.

Note 2: If power is applied to VCCIO and no power is applied to VCC all IOs will be at an unknown state, this however will not damage the chip. The FT231X also has protective circuitry to prevent the chip being damaged by a voltage discrepancy between VCCIO and the level of the signal being processed.

Note 3: When using VCCIO less than 3V3 on a chip from FTDI's X-chip range, it is recommended to use pull up resistors (47K) to VCCIO on the data lines, all of the UMFT2xxXE devices include an on-board pull-up for these lines.



### 5.6 3.3V Voltage Supply



Jumper JP1 - Closed

Jumper JP2 - Open

#### Figure 5.5 – USB Self Powered 3.3V Logic Drive

The FT231X can be powered from a single 3.3V supply. This feature is an alternative to having the FT231X powered at 5V in standard self-powered configuration.

The 3.3V Self Powered configuration is illustrated in Figure 5.5. Note that the 3.3V input is connected to VCC, VCCIO and 3V3OUT.

### 5.7 Configuring the MTP ROM

The FT231X contains an embedded MTP ROM. This can be used to configure the functions of each CBUS pin, the current drive on each signal pin, current limit for the USB bus and the other descriptors of the device. For details on using the MTP ROM/EEPROM programming utility FT\_PROG, please see the <u>FT\_PROG User Guide.</u>

When programming the MTP ROM please note:

- i) One of the CBUS Pins can be configured as PWREN# in the internal MTP ROM. This can be used to switch the power supply to the external circuitry.
- ii) The Max Bus Power setting of the MTP ROM should specify the maximum current to be drawn from the USB host/hub when enumerated. For high-powered USB devices the current limit when enumerated is between 100mA and 500mA, for low-powered USB devices the current limit is 100mA.



## **6 Module Dimensions**





Figure 6.1 – UMFT231XE Module Dimensions

All dimensions are given in millimetres.

The UMFT231XE module exclusively uses lead free components, and is fully compliant with European Union directive 2002/95/EC.



## 7 UMFT231XE Module Circuit Schematic



14 Copyright © 2012 Future Technology Devices International Limited



## 8 Internal MTP ROM Configuration

Following a power-on reset or a USB reset the FT231X will scan its internal MTP ROM and read the USB configuration descriptors stored there. The default values programmed into the internal MTP ROM in the FT231XQ used on the UMFT231XE are shown in Table 8.1.

| Parameter                            | Value       | Notes   |
|--------------------------------------|-------------|---|
| USB Vendor ID (VID)                  | 0403h       | FTDI default VID (hex)  |
| USB Product UD (PID)                 | 6015h       | FTDI default PID (hex)  |
| Serial Number Enabled?               | Yes         |   |
| Serial Number                        | See Note    | A unique serial number is generated and programmed into the MTP ROM during final test of the UM232R module.   |
| Pull down I/O Pins in USB<br>Suspend | Disabled    | Enabling this option will make the device pull down on the UART interface lines when the power is shut off (PWREN# is high).                                  |
| Manufacturer Name                    | FTDI        |   |
| Product Description                  | UMFT231XE   |   |
| Max Bus Power Current                | 90mA        |   |
| Power Source                         | Bus Powered |   |
| Device Type                          | FT231X      |   |
| USB Version                          | 0200        | Returns USB 2.0 device description to the host. Note: The device is a USB 2.0 Full Speed device (12Mb/s) as opposed to a USB 2.0 High Speed device (480Mb/s). |
| Remote Wake Up                       | Enabled     | Taking RI# low will wake up the USB host controller from suspend.   |
| High Current I/Os                    | Disabled    | Enables the high drive level on the UART and CBUS I/O pins.   |
| Load VCP Driver                      | Enabled     | Makes the device load the CVP driver interface for the device.  |
| CBUS0                                | GPIO        |   |
| CBUS1                                | GPIO        |   |
| CBUS2                                | GPIO        |   |
| CBUS3                                | GPIO        |   |
| Invert UART                          | Disabled    | Signal on this pin becomes TXD# if enable.  |

Table 8.1 – Default Internal MTP ROM Configuration

The internal MTP ROM in the FT231X can be programmed over USB using the utility program FT\_PROG. FT\_PROG can be downloaded from the <u>www.ftdichip.com</u>. Users who do not have their own USB vendor ID but who would like to use a unique Product ID in their design can apply to FTDI for a free block of unique PIDs. Contact <u>FTDI Support</u> (support1@ftdichip.com) for this service, also see <u>TN 100</u> and <u>TN 101</u>.



## 9 Contact Information

#### Head Office - Glasgow, UK

Future Technology Devices International Limited Unit 1, 2 Seaward Place, Centurion Business Park Glasgow G41 1HH United Kingdom Tel: +44 (0) 141 429 2777 Fax: +44 (0) 141 429 2758

E-mail (Sales)sales1@ftdichip.comE-mail (Support)support1@ftdichip.comE-mail (General Enquiries)admin1@ftdichip.com

#### Branch Office – Taipei, Taiwan

Future Technology Devices International Limited (Taiwan) 2F, No. 516, Sec. 1, NeiHu Road Taipei 114 Taiwan , R.O.C. Tel: +886 (0) 2 8791 3570 Fax: +886 (0) 2 8791 3576

E-mail (Sales) E-mail (Support) E-mail (General Enquiries)

tw.sales1@ftdichip.com tw.support1@ftdichip.com tw.admin1@ftdichip.com

#### Branch Office - Hillsboro, Oregon, USA

Future Technology Devices International Limited (USA) 7235 NW Evergreen Parkway, Suite 600 Hillsboro, OR 97123-5803 USA Tel: +1 (503) 547 0988 Fax: +1 (503) 547 0987

E-Mail (Sales) E-Mail (Support) E-Mail (General Enquiries) us.sales@ftdichip.com us.support@ftdichip.com us.admin@ftdichip.com

#### Branch Office – Shanghai, China

Future Technology Devices International Limited (China) Room 1103, No. 666 West Huaihai Road, Shanghai, 200052 China Tel: +86 (0)21 6235 1596 Fax: +86 (0)21 6235 1595

E-mail (Sales) E-mail (Support) E-mail (General Enquiries) <u>cn.sales@ftdichip.com</u> <u>cn.support@ftdichip.com</u> <u>cn.admin@ftdichip.com</u>

#### Web Site

http://ftdichip.com

#### **Distributor and Sales Representatives**

Please visit the Sales Network page of the <u>FTDI Web site</u> for the contact details of our distributor(s) and sales representative(s) in your country.

System and equipment manufacturers and designers are responsible to ensure that their systems, and any Future Technology Devices International Ltd (FTDI) devices incorporated in their systems, meet all applicable safety, regulatory and system-level performance requirements. All application-related information in this document (including application descriptions, suggested FTDI devices and other materials) is provided for reference only. While FTDI has taken care to assure it is accurate, this information is subject to customer confirmation, and FTDI disclaims all liability for system designs and for any applications assistance provided by FTDI. Use of FTDI devices in life support and/or safety applications is entirely at the user's risk, and the user agrees to defend, indemnify and hold harmless FTDI from any and all damages, claims, suits or expense resulting from such use. This document is subject to change without notice. No freedom to use patents or other intellectual property rights is implied by the publication of this document. Neither the whole nor any part of the information contained in, or the product described in this document, may be adapted or reproduced in any material or electronic form without the prior written consent of the copyright holder. Future Technology Devices International Ltd, Unit 1, 2 Seaward Place, Centurion Business Park, Glasgow G41 1HH, United Kingdom. Scotland Registered Company Number: SC136640



## Appendix A - List of Figures and Tables

| List of Figures   |    |
|---|----|
| Figure 4.1 – Module Pin Out                                 | 4  |
| Figure 5.1 – Bus Powered Configuration                      | 8  |
| Figure 5.2 – Self-Powered Configuration                     | 9  |
| Figure 5.3 – Bus Powered with Power Switching Configuration | 10 |
| Figure 5.4 – USB Bus Powered 3.3V Logic Drive               | 11 |
| Figure 5.5 – USB Self Powered 3.3V Logic Drive              | 12 |
| Figure 6.1 – UMFT231XE Module Dimensions                    | 13 |
| Figure 7.1 – Module Circuit Schematic                       | 14 |

#### List of Tables

| Table 4.1 – Module Pin Out Description             | . 5 |
|--|-----|
| Table 4.2 – CBUS Signal Options                    | . 6 |
| Table 5.1 – Jumper JP1 Pin Description             | . 7 |
| Table 5.2 – Jumper JP2 Pin Description             | . 7 |
| Table 8.1 – Default Internal MTP ROM Configuration | 15  |