

## SC2602L Synchronous Voltage Mode Controller for Distributed Power Supply

#### POWER MANAGEMENT

#### **Description**

The SC2602L is low-cost, full featured, synchronous voltage-mode controller designed for use in single ended power supply applications where efficiency is of primary concern. Synchronous operation allows for the elimination of heat sinks in many applications. The SC2602L is ideal for implementing DC/DC converters needed to power advanced microprocessors in low cost systems, or in distributed power applications where efficiency is important. Internal level-shift, high-side drive circuitry, and preset shoot-through control, allows the use of inexpensive N-channel power MOSFETs.

SC2602L features include temperature compensated voltage reference, triangle wave oscillator and current sense comparator circuitry. Power good signaling, shutdown, and over voltage protection are also provided.

The SC2602L operates at a fixed 200kHz which is for optimum compromise between efficiency, external component size, and cost.

Two SC2602L can be used together to sequence two voltage regulators for power up in telecom systems. The power good of the first SC2602L connected to the enable of the second SC2602L makes this possible.

#### Features

- ◆ Synchronous operation for high efficiency (95%)
- $R_{DS(ON)}$  current sensing
- Output voltage can be programmed as low as 0.8V
- On-chip power good and OVP functions
- Small size with minimum external components
- Soft Start
- Enable function
- SO-14 package is fully WEEE and RoHS compliant

#### Applications

- Microprocessor core supply
- Low cost synchronous applications
- Voltage Regulator Modules (VRM)
- DDR termination supplies
- Networking power supplies
- Sequenced power supplies



#### Absolute Maximum Ratings

EMTECH

Exceeding the specifications below may result in permanent damage to the device, or device malfunction. Operation outside of the parameters specified in the Electrical Characteristics section is not implied. Exposure to Absolute Maximum rated conditions for extended periods of time may affect device reliability.



Note: (1) -1.5V to 20V for 25ns repetitive every cycle.

#### Electrical Characteristics

Unless specified: V<sub>cc</sub> = 4.75V to 12.6V; GND = PGND = 0V; V<sub>BSTL</sub> = 12V; V<sub>BSTH-PHASE</sub> = 12V; T<sub>J</sub> = 25°C



# EMTECH

#### POWER MANAGEMENT

#### Electrical Characteristics (Cont.)

Unless specified: V<sub>cc</sub> = 4.75V to 12.6V; GND = PGND = 0V; V<sub>BSTL</sub> = 12V; V<sub>BSTH-PHASE</sub> = 12V; T<sub>J</sub> = 25°C



Note:

(1) Specification refers to application circuit (Figure 1).

## SC2602L



## POWER MANAGEMENT



#### **Pin Descriptions**

### Pin Configuration **Pin Configuration** Construction Configuration



#### Notes:

(1) Only available in tape and reel packaging. A reel contains 2500 devices.

(2) Lead free product. This product is fully WEEE and RoHS compliant.



#### Note:

(1) All logic level inputs and outputs are open collector TTL compatible.





#### Block Diagram



#### Synchronous Buck Converter

The output rail is regulated by a synchronous, voltagemode pulse width modulated (PWM) controller. This section has all the features required to build a high efficiency synchronous buck converter, including "Power Good" flag, shut-down, and cycle-by-cycle current limit.

The output voltage of the synchronous converter is set and controlled by the output of the error amplifier. The external resistive divider reference voltage is derived from an internal trimmed-bandgap voltage reference (See Fig. 1). The inverting input of the error amplifier receives its voltage from the SENSE pin.

The internal oscillator uses an on-chip capacitor and trimmed precision current sources to set the oscillation frequency to 200kHz. The triangular output of the oscillator sets the reference voltage at the inverting input of the comparator. The non-inverting input of the comparator receives it's input voltage from the error amplifier. When the oscillator output voltage drops below the error amplifier output voltage, the comparator output goes high. This pulls DL low, turning off the low-side FET, and DH is pulled high, turning on the high-side FET (once the cross-current control allows it). When the oscillator voltage rises back above the error amplifier output voltage, the comparator output goes low. This pulls DH low, turning off the high-side FET, and DL is pulled high, turning on the low-side FET (once the cross-current control allows it).

As SENSE increases, the output voltage of the error amplifier decreases. This causes a reduction in the ontime of the high-side MOSFET connected to DH, hence lowering the output voltage.

#### Under Voltage Lockout

The under voltage lockout circuit of the SC2602L assures that the high-side MOSFET driver outputs remain in the off state whenever the supply voltage drops below set parameters. Lockout occurs if  $V_{cc}$  falls below 4.1V. Normal operation resumes once  $V_{cc}$  rises above 4.2V.

#### Over-Voltage Protection

The over-voltage protection pin (OVP) is high only when the voltage at SENSE is 20% higher than the target value programmed by the external resistor divider. The OVP pin is internally connected to a PNP's collector.

#### Power Good

The power good function is to confirm that the regulator outputs are within +/-10% of the programmed level. PWRGD remains high as long as this condition is met. PWRGD is connected to an internal open collector NPN transistor.

**EMTECH** 

#### Applications Information (Cont.)

#### Soft Start

Initially, SS/SHDN sources 10µA of current to charge an external capacitor. The outputs of the error amplifiers are clamped to a voltage proportional to the voltage on SS/SHDN. This limits the on-time of the high-side MOSFETs, thus leading to a controlled ramp-up of the output voltages.

#### $R_{DS(ON)}$  Current Limiting

The current limit threshold is set by connecting an external resistor from the  $V_{cc}$  supply to OCSET. The voltage drop across this resistor is due to the 200µA internal sink sets the voltage at the pin. This voltage is compared to the voltage at the PHASE node. This comparison is made only when the high-side drive is high to avoid false current limit triggering due to uncontributing measurements from the MOSFETs off-voltage. When the voltage at PHASE is less than the voltage at OCSET, an overcurrent condition occurs and the soft start cycle is initiated. The synchronous switch turns off and SS/ SHDN starts to sink 1.5µA. When SS/SHDN reaches 0.8V, it then starts to source 10µA and a new cycle begins.

#### Hiccup Mode

During power up, the SS/SHDN pin is internally pulled low until VCC reaches the undervoltage lockout level of 4.2V. Once  $V_{cc}$  has reached 4.2V, the SS/SHDN pin is released and begins to source 10µA of current to the external soft-start capacitor. As the soft-start voltage rises, the output of the internal error amplifier is clamped to this voltage. When the error signal reaches the level of the internal triangular oscillator, which swings from 1V to 2V at a fixed frequency of 200kHz, switching occurs. As the error signal crosses over the oscillator signal, the duty cycle of the PWM signal continues to increase until the output comes into regulation. If an overcurrent condition has not occurred the soft-start voltage will continue to rise and level off at about 2.2V.

An over-current condition occurs when the high-side drive is turned on, but the PHASE node does not reach the voltage level set at the OCSET pin. The PHASE node is sampled only once per cycle during the valley of the triangular oscillator. Once an over-current occurs, the highside drive is turned off and the low-side drive turns on and the SS/SHDN pin begins to sink 1.5µA. The softstart voltage will begin to decrease as the 1.5µA of current discharges the external capacitor. When the softstart voltage reaches 0.8V, the SS/SHDN pin will begin to source  $10\mu A$  and begin to charge the external capacitor causing the soft-start voltage to rise again. Again, when the soft-start voltage reaches the level of the internal oscillator, switching will occur.

If the over-current condition is no longer present, normal operation will continue. If the over-current condition is still present, the SS/SHDN pin will again begin to sink 1.5µA. This cycle will continue indefinitely until the overcurrent condition is removed.

In conclusion, below is shown a typical "12V Application Circuit" which has a BSTH voltage derived by bootstrapping input voltage to the PHASE node through diode D1. This circuit is very useful in cases where only input power of 12V is available.

In order to prevent substrate glitching, a small-signal diode should be placed in close proximity to the chip with cathode connected to PHASE and anode connected to PGND.

## SC2602L



#### Application Circuit









Typical Characteristics

Output Ripple Voltage Ch1: Vo\_rpl

1.  $V_{\text{IN}}$  = 5V;  $V_{\text{O}}$  = 3.3V;  $I_{\text{OUT}}$  = 12A



Gate Drive Waveforms Ch1: Top FET Ch2: Bottom FET





Ch1: Vo\_rpl Ch1: Vo\_rpl<br>
2. V<sub>IN</sub> = 5V; V<sub>OUT</sub> = 1.3V; I<sub>OUT</sub> = 12A Ch2: Bottom



Ch2: Bottom FET



**SEMTECH** 

## SC2602L

 $4.4V$ 



#### Typical Characteristics (Cont.)

SEMTECH

#### Hiccup Mode



#### Start Up Mode







Fig. 2. SC2602L small signal model.

The control model of SC2602L control loop small signal can be depicted in Fig. 2. This model can also be used in SPICE kind of simulator to generate loop gain Bode plots. The bandgap reference is  $0.8V$  and trimmed to  $+/1\%$ accuracy. The desired output voltage can be achieved by setting the resistive divider network, R1 and R2.

The error amplifier is transconductance type with fixed gain of:

$$
G_m := \frac{1.8 \cdot mA}{V}
$$

The compensation network includes a resistor and a capacitor in series, which terminates from the output of the error amplifier to the ground.

This device uses voltage mode control with input voltage feed forward. The peak-to-peak ramp voltage is proportional to the input voltage, which results in an excellent performance to reject input voltage variation. The PWM gain is inversion of the ramp amplitude, and this gain is given by:

$$
G_{\text{pwm}} := \frac{1}{V_{\text{ramp}}}
$$

where the ramp amplitude (peak-to-peak) is 1.0 volts when input voltage is 12 volts.

The total control loop-gain can then be derived as follows:

$$
T(s)=T_o \cdot \left(\frac{1+s \cdot R \cdot C}{s \cdot R \cdot C}\right) \cdot \frac{1+s \cdot R \cdot C \cdot C_o}{1+s \cdot \left(R \cdot C_o + \frac{L}{R_o}\right) + s^2 \cdot L \cdot C_o \cdot \left(1+\frac{R \cdot C}{R_o}\right)}
$$

$$
T_o := G_m \cdot G_{\text{pwm}} \cdot V_{\text{in}} \cdot R \cdot \left(\frac{V_{\text{bg}}}{V_o}\right)
$$

The task here is to properly choose the compensation network for a nicely shaped loop-gain Bode plot. The following design procedures are recommended to accomplish the goal:

(1) Calculate the corner frequency of the output filter:

$$
F_o := \frac{1}{2 \cdot \pi \sqrt{L.C_o}}
$$

(2) Calculate the ESR zero frequency of the output filter capacitor:

$$
F_{\text{esr}} := \frac{1}{2 \cdot \pi \cdot R_{\text{c}} \cdot C_{\text{o}}}
$$

(3) Check that the ESR zero frequency is not too high.

$$
F_{\text{ esr}} < \frac{F_{\text{ sw}}}{5}
$$

If this condition is not met, the compensation structure may not provide loop stability. The solution is to add some electrolytic capacitors to the output capacitor bank to correct the output filter corner frequency and the ESR zero frequency. In some cases, the filter inductance may also need to be adjusted to shift the filter corner frequency. It is not recommended to use only high frequency multi-layer ceramic capacitors for output filter.

(4) Choose the loop gain cross over frequency (0 dB frequency). It is recommended that the crossover frequency is always less than one fifth of the switching frequency :

$$
F_{x\_over} \le \frac{F_{sw}}{5}
$$

If the transient specification is not stringent, it is better to choose a crossover frequency that is less than one tenth of the switching frequency for good noise immunity. The resistor in the compensation network can then be calculated as:

$$
R := \frac{1}{G_{\text{pwm}} \cdot V_{\text{in}} \cdot G_{\text{m}}} \cdot \left(\frac{F_{\text{esr}}}{F_{\text{o}}}\right)^{2} \cdot \left(\frac{F_{x\_over}}{F_{\text{esr}}}\right) \cdot \left(\frac{V_{\text{o}}}{V_{\text{bg}}}\right)
$$

when

$$
F_0 < F_{\text{esr}} < F_{\text{x-over}}
$$



Applications Information (Cont.)

or

$$
R := \frac{1}{G_{\text{pwm}} \cdot V_{\text{in}} \cdot G_{\text{m}}} \cdot \left(\frac{F_o}{F_{\text{esr}}}\right)^2 \cdot \left(\frac{F_{x\_over}}{F_o}\right) \cdot \left(\frac{V_o}{V_{bg}}\right)
$$

when

$$
F_{\text{esr}} < F_0 < F_{\text{x-over}}
$$

(5) The compensation capacitor is determined by choosing the compensator zero to be about one fifth of the output filter corner frequency:

$$
F_{zero} := \frac{F_o}{5}
$$

$$
C := \frac{1}{2 \cdot \pi \cdot R \cdot F_{zero}}
$$

(6) The final step is to generate the Bode plot, either by using the simulation model in Fig. 2 or using the equations provided here with Mathcad. The phase margin can then be checked using the Bode plot. Usually, this design procedure ensures a healthy phase margin.

(7) An additional capacitor should be reserved at the compensation pin to ground to have another high frequency pole.

An example is given below to demonstrate the procedure introduced above. The parameters of the power supply are given as :

The parameters of the power supply are given as :

 $V_i$  := 12 V.

$$
V_0 := 3.3 \text{ V}
$$
  
\n
$$
V_0 := 12 \text{ A}
$$
  
\n
$$
F_{sw} := 200 \text{ KHz}
$$
  
\n
$$
L := 4 \cdot \mu \text{ H}
$$
  
\n
$$
C_0 := 1200 \mu \text{ F}
$$
  
\n
$$
R_c := 0.02 \Omega
$$
  
\n
$$
V_{bg} := 0.8 \text{ V}
$$
  
\n
$$
V_{ramp} := 1.8 \text{ mA}
$$

Step 1. Output filter corner frequency

 $F_{0} = 2.5166$ KHz

SC2602L

Step 2. ESR zero frequency:

$$
F_{\text{esr}} = 7.958 \text{K} \text{Hz}
$$

Step 3. Check the following condition:

$$
F_{\text{esr}} < \frac{F_{\text{sw}}}{5}
$$

Which is satisfied in this case.

Step 4. Choose crossover frequency and calculate compensator R:

$$
F_{X_{\text{over}}} = 20 \text{eKHz}
$$

 $R = 4.8$  K $\Omega$ 

Step 5. Calculate the compensator C:

#### $C = 65.886$ mF

Step 6. Generate Bode plot and check the phase margin. In this case, the phase margin is about 85°C that ensures the loop stability.



SC2602L

#### POWER MANAGEMENT

#### Applications Information (Cont.)

