[New Release]

Renesas Starter Kit+ for RX72M

R20TS0514EJ0100 Rev.1.00 Dec. 01, 2019

- Releasing RX72M Evaluation Environment with Industrial Ethernet Communication EtherCAT® Support -

Overview

The Renesas Starter Kit+ for RX72M for the RX family RX72M group will be released.

1. Product Overview

The Renesas Starter Kit+ for RX72M is the optimal starter kit for developers to get started with the RX72M group.

The kit includes the following hardware needed for development.

- Hardware
- CPU board including RX72M group (Code Flash 4MB, Pin Count 224-pin) device
- Pmod™ Compatible LCD board
- E2 emulator Lite
- 5V AC adapter (Multi Region)



Figure 1 Renesas Starter Kit+ for RX72M

Software

The Renesas Starter Kit+ for RX72M installer, which includes software needed for evaluation, is available at the URL below. With the Renesas Starter Kit+ for RX72M and these tools, developers can start evaluation immediately.

 Download URL for Renesas Starter Kit+ for RX72M https://www.renesas.com/rskrx72m#downloads The Renesas Starter Kit+ for RX72M installer*1 includes the following software.

- · Integrated development environment (CS+/e² studio)
- · C/C++ Compiler Package for RX Family Evaluation Edition
- · Renesas Flash Programmer Evaluation Edition
- · Renesas Starter Kit+ for RX72M Sample Program
 - *1: Two types of installer are available: e² studio IDE version and CS+ IDE version.

For details about the Renesas Starter Kit+ for RX72M, see the URL below.

 Renesas Starter Kit+ for RX72M product page https://www.renesas.com/rskrx72m

2. Product Features

- Evaluates features of EtherCAT®
- 1 channel USB allows evaluation of host/ function
- > Evaluates RSPI (Renesas Serial Peripheral Interface) and QSPI (Quad Serial Peripheral Interface)
- SD slot enables evaluation of SD host interface (SDHI)
- RX72M with built-in Trusted Secure IP *1 to support evaluation of security features of AES encryption and robust key management
 - *1: Trusted Secure IP is a security function that protects the communication data and saves the encryption key securely.




Figure 2 CPU Board (Component side)

3. Operating Environment

- · IBM PC/AT compatibles
- · Windows® 10 (32-bit, 64-bit version)
- · Windows 8.1 (32-bit, 64-bit version)
- · Windows 7 (32-bit, 64-bit version)
- · Processor: 1 GHz or higher (supports hyper-threading, multi-core CPU)
- Memory capacity: recommended 2 GB or more, at least 1 GB (at least 2 GB for Windows 10 and Windows 64-bit version)
- · Hard disk capacity: at least 1 GB of free space
- · Display: At least 1024×768 resolution, 65536 colors or more

4. Purchasing the Product

For product ordering, contact your local Renesas Electronics sales office or distributor with the following information.

For product pricing, make inquiries in the same manner.

Product part number (Orderable part number)	Trusted Secure IP	Release schedule
RTK5572MNDS10000BE	No	Available
RTK5572MNHS10000BE	Yes	March 2020, or later

R20TS0514EJ0100 Rev.1.00 Page 3 of 4
Dec.01.19