

# Sure Cross® 3Q Temperature and Humidity Sensor



## Datasheet



The Sure Cross® Temperature and Humidity Sensor works in a variety of environments to provide temperature and humidity measurements.

- Manufactured with a robust metal housing
- Functions as a Modbus slave device via RS-485
- Ships with aluminum grill filter cap; optional stainless steel 10 micrometer sintered filter available separately
- 3Q and 4Q models are calibrated and traceable to NIST standards



### WARNING:

- **Do not use this device for personnel protection**
- Using this device for personnel protection could result in serious injury or death.
- This device does not include the self-checking redundant circuitry necessary to allow its use in personnel safety applications. A device failure or malfunction can cause either an energized (on) or de-energized (off) output condition.

For additional information, updated documentation, and a list of accessories, refer to Banner Engineering's website, [www.bannerengineering.com](http://www.bannerengineering.com).

Configure this sensor using the [Sensor Configuration Software](#) and adapter cable BWA-HW-006 (datasheet [140377](#)).

## Models

| Models   | Accuracy     | Calibration <sup>1</sup> | I/O   |
|----------|--------------|--------------------------|---|
| M12FTH3Q | ±2% at 25 °C | Yes                      | Temperature and relative humidity via RS-485 Modbus |
| M12FT3Q  | ±2% at 25 °C | Yes                      | Temperature via RS-485 Modbus                       |

**Banner Humidity Sensor Calibration Statement.** This calibration statement (also available online) lists the chain with which the calibration of Banner humidity sensors is traceable to NIST standards. A Certificate of Factory Calibration ships with every 3Q and 4Q model sensor. Although your certificate will be specific to your product, a sample certificate is available for [download](#).

## Configuration Instructions

### Sensor Configuration Software

The Sensor Configuration Software offers an easy way to manage sensor parameters, retrieve data, and visually show sensor data from a number of different sensors. The Sensor Configuration Software runs on any Windows machine and uses an adapter cable to connect the sensor to your computer.

Download the most recent version of the software from Banner Engineering's website: [www.bannerengineering.com](http://www.bannerengineering.com) and select **Software** from the **Products** drop-down list.

Table 1: The Sensor Configuration Software supports the following sensors

| Sensor Type               | Model                | USB Adapter Cable   |
|---------------------------|----------------------|---|
| Temperature and Humidity  | M12FTH3Q and M12FT3Q | USB-to-RS-485 adapter cable model <b>BWA-HW-006</b> OR USB to RS-485 adapter cable model <b>BWA-UCT-900</b> (datasheet p/n <a href="#">140377</a> )   |
|                           | M12FTH4Q and M12FT4Q | USB-to-RS-232 1-Wire adapter cable model <b>BWA-USB1WIRE-001</b> (datasheet p/n <a href="#">170020</a> )  |
| Vibration and Temperature | QM42VT1              | USB-to-RS-232 1-Wire adapter cable model <b>BWA-USB1WIRE-001</b> (datasheet p/n <a href="#">170020</a> )  |
|                           | QM42VT2              | USB-to-RS-485 adapter cable model <b>BWA-HW-006</b> OR USB to RS-485 adapter cable model <b>BWA-UCT-900</b> (datasheet p/n <a href="#">140377</a> ). When updating the firmware, you must use one of the two USB to RS-485 adapter cables plus a splitter pigtail cable p/n 83265.                  |
|                           | QM30VT1              | USB-to-RS-232 1-Wire adapter cable model <b>BWA-USB1WIRE-001</b> (datasheet p/n <a href="#">170020</a> )  |
|                           | QM30VT2              | USB to RS-485 adapter cable model <b>BWA-UCT-900</b> (datasheet p/n <a href="#">140377</a> ). When updating the firmware, you must use one of the two USB to RS-485 adapter cables.   |
| GPS                       | GPS50M               | USB-to-RS-485 adapter cable model <b>BWA-HW-006</b> AND a field-wireable M12/Euro-style connector or connector with pigtail OR USB to RS-485 adapter cable model <b>BWA-UCT-900</b> AND a field-wireable M12/Euro-style connector or connector with pigtail (datasheet p/n <a href="#">140377</a> ) |

<sup>1</sup> 3Q and 4Q models are calibrated and traceable to NIST standards




| Sensor Type            | Model     | USB Adapter Cable   |
|------------------------|-----------|---|
| U-GAGE K50U Ultrasonic | K50UX1CRA | USB-to-RS-232 1-Wire adapter cable model <b>BWA-USB1WIRE-001</b> (datasheet p/n <a href="#">170020</a> )  |
|                        | K50UX2CRA | USB-to-RS-485 adapter cable model <b>BWA-HW-006</b> OR USB to RS-485 adapter cable model <b>BWA-UCT-900</b> (datasheet p/n <a href="#">140377</a> ) |
|                        | K50UX1ARA | USB-to-RS-232 1-Wire adapter cable model <b>BWA-USB1WIRE-001</b> (datasheet p/n <a href="#">170020</a> )  |
|                        | K50UX2ARA | USB-to-RS-485 adapter cable model <b>BWA-HW-006</b> OR USB to RS-485 adapter cable model <b>BWA-UCT-900</b> (datasheet p/n <a href="#">140377</a> ) |

Refer to the Sensor Configuration Software Instruction Manual (p/n [170020](#)) to update your sensor's firmware.

## Connect the Temperature/Humidity Sensor

Figure 1. Connect the sensor



To install the sensor to a device with a 5-pin M12 female end:

1. Align the notch in the female connector with the key in the sensor's male connector.
2. Gently slide the sensor end into the connector.
3. Rotate the threaded nut to tighten the sensor down. DO NOT attempt to rotate the sensor after it is connected to the device or the cable end because this will damage the sensor.

## Wiring

Table 2: 5-pin M12 male connector wiring

| 5-pin M12 Male Connector | Pin | Wire Color | Sensor Connection  |
|--------------------------|-----|------------|--|
|                          | 1   | Brown      | Power IN (+). Either 3.6–5.5 V DC (Low Power Mode) or 12–24 V DC   |
|                          | 2   | White      | RS485 / D1 / B / +   |
|                          | 3   | Blue       | Ground (-)   |
|                          | 4   | Black      | RS485 / D0 / A / -   |
|                          | 5   | Gray       | For 12–24 V DC operation: Not Used<br>For 3.6–5.5 V DC operation: Discrete NPN Select Line. Pull to ground to enable serial communications; release from ground to disable serial communications |

Refer to the Class I Division 2 control drawings (p/n [143086](#)) for wiring specifications and limitations.

Low Power Mode operation (3.6–5.5 V DC operating voltage) offers the user savings in power consumption by putting the Banner Temperature and Humidity Sensor's serial communications to sleep whenever the sensor is deselected. Low Power Mode operation is ideal for battery-powered applications or any application with power consumption restrictions. When the sensor is deselected, power consumption drops to 45  $\mu$ A. When the sensor is selected, power consumption is 4 mA.

To operate the Banner Temperature and Humidity Sensor in Low Power Mode, the supply voltage applied to Power In must be within the range of 3.6–5.5 V DC. Set the Select Line to 0 V (ground) to select the sensor and activate the sensor's serial communications. Release the Select Line from 0 V (ground) to deselect the sensor and disable the sensor's serial communications. When deselected, the sensor's green LED continues to blink normally. To bypass Low Power Mode, connect the Select Line to ground (0 V).

For example, to use Low Power Mode, use 3.6 V DC battery power and connect the Select Line to Discrete Output 1 (NMOS output, low active).

## Holding Registers

Humidity measurements are only available on the **M12FTH3Q** model. A humidity sensor is not included with the **M12FT3Q** model.

Table 3: Modbus holding registers

| Sensor Address | Description          | I/O Range                          |           | Holding Register Representation |           |
|----------------|----------------------|------------------------------------|-----------|---------------------------------|-----------|
|                |                      | Min Value                          | Max Value | Min (Dec)                       | Max (Dec) |
| 40001          | Humidity (%RH)       | 0                                  | 100.00%   | 0                               | 10,000    |
| 40002          | Temperature (°C)     | -1638.4                            | 1638.3    | -32768                          | 32767     |
| 40003          | Temperature (°F)     | -1638.4                            | 1638.3    | -32768                          | 32767     |
| 46101          | Baud                 | 0=9.6k, 1=19.2k (default), 2=38.4k |           |                                 |           |
| 46102          | Parity               | 0=none (default), 1=odd, 2=even    |           |                                 |           |
| 46103          | Modbus slave address | 1 (default) through 247            |           |                                 |           |

The temperature = (Modbus register value) ÷ 20. The humidity = (Holding register value) ÷ 100.

## Specifications

### Supply Voltage

12 to 24 V DC OR 3.6 to 5.5 V DC low power option

### Current

Default sensing: 45 µAmps  
 Disabled sensing: 32 µAmps  
 Active comms: 4 mA

### Discrete Input

One, NPN/Sinking  
 Rating: 3 mA max current at 30 V DC  
 Sample Rate: 125 milliseconds  
 ON Condition (NPN): Less than 0.7 V  
 OFF Condition (NPN): Greater than 2 V or open

### Temperature

Measuring Range: -40 °C to +85 °C (-40 °F to +185 °F) <sup>2</sup>  
 Resolution: 0.1 °C  
 Accuracy  
 -40 °C to 0 °C: ± 0.6 °C  
 0 °C to 60 °C: ± 0.4 °C  
 +60 °C to +85 °C: ± 1.2 °C

Operating the Modbus temperature/humidity sensor at voltages greater than 12 V can increase the temperature accuracy error by up to 1 °C. The amount of error depends upon the application's device mounting and air flow characteristics.

### Humidity

Humidity measurements are only available with model M12FTH3Q. Model M12FT3Q does not include the humidity sensor.  
 Measuring Range: 0 to 100% relative humidity (RH)  
 Resolution: 0.1% relative humidity  
 Accuracy:  
 ±2% at 25 °C  
 ±3% at 0 °C to 70 °C and 10–90% RH  
 ± 7% at 0 °C to 70 °C and 0–10 % or 90–100 % RH

### Environmental Rating

IEC IP67; NEMA 6

### Operating Temperature

-40 °C to +85 °C (-40 °F to +185 °F)

### Shock and Vibration

All models meet IEC 60068-2-6 and IEC 60068-2-27 testing criteria  
 Shock: 30G 11 ms duration, half sine wave per IEC 60068-2-27  
 Vibration: 10 Hz to 55 Hz, 0.5 mm peak-to-peak amplitude per IEC 60068-2-6

### Mounting Threads

M12 × 1

### Indicators

Green flashing: Power ON  
 Red flicker: Serial Tx

### Temperature and/or Humidity Input

Sample Rate: 16 seconds

### Communication

Interface: RS-485 serial  
 Baud rates: 9.6k, 19.2k (default), or 38.4k  
 Data format: 8 data bits, no parity (default), 1 stop bit (even or odd parity available)  
 Protocol: Modbus RTU

### Certifications



CSA: Class I, Division 2, Groups A, B, C, D — Certificate 1921239

Refer to the Class I Division 2 control drawings (p/n 143086) for wiring specifications and limitations. All battery-powered devices must only use the lithium battery manufactured by Xeno, model XL-205F (Banner model number **BWA-BATT-001**).



**Banner Engineering**  
 Europe Park Lane,  
 Culliganlaan 2F bus 3,  
 1831 Diegem,  
 BELGIUM

**Turck Banner LTD**  
 Blenheim House,  
 Blenheim Court,  
 Wickford, Essex SS11  
 8YT, Great Britain

<sup>2</sup> Operating the devices at the maximum operating conditions for extended periods can shorten the life of the device.