

## FemtoDLynxII™ Series Evaluation Board Documentation

The FemtoDLynxII<sup>TM</sup> series evaluation board (FKX003/006)) comes with an assembled module and test components. The specific combination of module and the board can be ordered through your sales representative.

## 1. Schematics

Component values are for reference only; refer to the data sheet for appropriate values and pictures in this document for preinstalled component




Figure 1 - Schematic of the FemtoDLynx  $^{\text{\tiny{TM}}}$  single footprint evaluation board.

Component values are for reference only; refer to the data sheet for appropriate values and pictures in this document for preinstalled components

January 15, 2020 ©2020 ABB All rights reserved. Page 1



## FemtoDLynxII<sup>™</sup> Evaluation Board Guide

## 2. Physical Description

An annotated photograph of the FemtoDLynxII<sup>TM</sup>, single footprint evaluation board is shown below. The arrows indicate locations of various components. Pre-Installed components for the FemtoDLynx<sup>TM</sup> - Input filtering (0.1uF, 16V), (4x22uF,16V),(470uF,16V)] 2 of the input capacitors on the bottom-side, Output filtering [(0.1uF, 16V), (4x22uF,16V)], R<sub>SENSE</sub> resistor,  $R_{21} = 0$  Ohms, Trim Resistor  $R_{6} = 20$ K and some test points.




Figure 2. Power and Analog Signal Interface for the Femto Eval Board

January 15, 2020 ©2020 ABB All rights reserved.