

# 4G/LTE/GSM MODEM with GPS

### Features:

- RS232+USB interface
- Based on Simcom SIM7600E-H
- TDD-LTE B38/B39/B40/B41
- FDD-LTE B1/B3/B8
- TD-SCDMA B34/B39
- UMTS/HSDPA/HSPA+ B1/B8
- CDMA 1X/EVDO BCO
- GSM/GPRS/EDGE 900/1800MHz
- LED Indicates power and GSM signal
- SMA Antenna Connector for GSM & GPS
- Rugged Aluminium Enclosure
- 1.8-3V SIM card slot
- Supply voltage 6-36Vdc
- Output Power:

Class4: 2W @ 850/ 900MHz GSM

Class1: 1W @ 1800/1900MHz GSM

Class3: 0.25W @ 850/1900/2100MHz

**UMTS** 

- GPS Sensitivity -159dBm
- GLONASS Sensitivity –158dBm
- Accuracy 2.5m (open sky)
- Receiver 16 Channel C/A code
- Update rate: Default 1 Hz
- GNSS data format: NMEA-0183



#### Kit Includes:

- GSM Modem
- Mounting Bracket
- GSM Antenna
- GPS Antenna
- Power Supply
- RS232 Cable
- USB Cable
- CD

Part Number	Description
GSM-4GLTEGPS	Modem Kit
SIMCARD	Please see website for various PAYG / Contract





### Key Features:

Features	Implementation	
Transmission	Data, SMS, Fax	
Power supply	Single supply voltage 6V—36Vdc	
Current Consumption	Standby ~55mA Working Current 100-140mA	
GSM class	Small MS. (GSM07.07 and 07.05)	
GPRS	Class 8	
Frequency bands	900, 1800	
Transmit power	Class 4 (2W) for 900MHz Class 1 (1W) for 1900MHz	
Supported SIM card	3V	
External antenna	Connected via antenna SMA connector	
Max Transmitting Speed	115KB/s	
FAX	Group 3: Class 1, Class 2	
Serial interface	<ul> <li>RS-232 interface, for AT commands and data</li> <li>Baud rates from 300bps to 115,200bps</li> </ul>	
Reset of Terminal	Reset via AT command	
Environmental Temperature:	<ul> <li>Working operation: -20°C to +55°C</li> <li>Humidity: max. 80% relative humidity</li> </ul>	
Size	76mmx54mmx25mm (Casing Dimension)	
Weight	100g (Approx.)	

DS-GSM-4GLTEGPS-1

### What's in the box?

- GSM Modem unit
- GPS Antenna
- 4G Antenna
- RS232 Cable
- Power Supply





### Interface Description:

The GSM Terminal provides the following connectors for power supply, interfacing and antenna:

- 2.1mm DC power connector (centre/inner pin is positive)
- 9-(female) D-SUB plug for RS-232 serial interface
- SMA connector for antenna (radio interface)
- SIM card holder





### Power Supply:

The power supply of the GSM terminal should be a single voltage source of Vin=6-32V providing peak current of up to 500mA during transmission.

The terminal can be turned on by connecting power. The terminal power supply circuit automatically generates a low pulse signal not less than 100ms in order to wake up the GSM engine.

Each time the terminal is shut down, data will be written from the volatile memory to the flash memory. The guaranteed maximum number of write cycles is limited to 100,000.

#### RS232 Interface

Via RS-232 interface, the host controller controls the TMAS GSM/GPRS terminal and transports data. The table below shows the pin assignment of RS-232 (D-SUB 9-pin female).

Pin no.	Signal name	1/0	Function
1	/DCD	0	Data Carrier Detected
2	/RXD	0	Receive Data
3	/TXD	_	Transmit Data
4	/DTR	_	Data Terminal Ready
5	GND	-	Ground
6	/DSR	0	Data Set Ready
7	/RTS	_	Request To Send
8	/CTS	0	Clear To Send
9	/RI	0	Ring Indication

The GSM/GPRS terminal is designed for use as DCE. Based on the conventions for DCE-DTE connection, it communicates with the user application (DTE) using the following signals:

Pin TxD @ application sends data to TxD of GSM/GPRS terminal

Pin RxD @ application receives data from RxD of GSM/GPRS terminal





### Status LED

The LED displays the operating status of the terminal. The table below summarises the coding of the red LED status.

Operating status	LED
Power Down	Off
Standby (Registered to the net)	On
Talk mode, GPRS data	Blinking

### Basic AT Command List:

The commands are listed in the document SIM7500\_SIM7600 Series\_AT Command Manual