


a. FPC MOUNTING

FPC must have suitable stiffener to prevent peeling of the solder joints during mating/unmating. We recommend the FPC to be supported with the reinforcement.

b. MULTI-CONNECTOR PLACEMENT

When mounting on a solid PCB on both sides do not place more than one connector on each side.

When mointing one side on a rigid PCB and other on the flexible printed circuit several connectors can be mountde on the rigid side. The FPC must have slats between each of the connectors to allow alignment with each corresponding connector.




MATING PRECAUTIONS


Connectors must be mated by hand only. Application of excessive forces may damage the connectors.

MATING PROCEDURES

1) Align mount plug (K.FL2-PR-SMT09) and receptacle (K.FL2-R-SMT-1) by slight touch as shown on fig. 1.



2) Confirm the alignment by applying slight even pressure to the mount plug (K.FL2-PR-SMT09) partially inserting it in the mount receptacle (K.FL2-R-SMT-1). as shown in fig. 2. The plug should not move sideways or be slanted.







FIG. 2

3) Push-down on the mount plug (K.FL2-PR-SMT09) until is fully inerted, confirming it with a tactile 'CLICK'








FIG. 3


4) When mating was not possible. Please use it after confirming that a plug receptacle female contact by the transformation or the mold part does not have transformation before just using a plug receptacle.




UNMATING PRECAUTIONS

Unmate by applying even vertical force to the mount plug (K.FL2-PR-SMT09) as shown on fig. 4. Do not rock or lift by one side only. FPC must have suitable stiffener.





If encountering sone resistance during the unmating start lifting from side as shown on fig. 5. Do not attempt unmating by lifting it from any of the other side.



SUGGESTIONS TO PREVENT ACCIDENTAL UNMATING

In environments where the connectors may encounter severe shock, vibration or FPC's bend spring-back it is advisable to provide additional support when connectors are fully mated. E.G.: device chassis or compressive cushion.

