

QBiP-8565A/ QBiP-8265A/ QBiP-8145A

3.5" SBC Boards
User's Manual 1st Ed

Copyright Notice

This document is copyrighted, 2018. All rights are reserved. The original manufacturer reserves the right to make improvements to the products described in this manual at any time without notice.

No part of this manual may be reproduced, copied, translated, or transmitted in any form or by any means without the prior written permission of the original manufacturer. Information provided in this manual is intended to be accurate and reliable. However, the original manufacturer assumes no responsibility for its use, or for any infringements upon the rights of third parties that may result from its use.

The material in this document is for product information only and is subject to change without notice. While reasonable efforts have been made in the preparation of this document to assure its accuracy, GIGAIPC assumes no liabilities resulting from errors or omissions in this document, or from the use of the information contained herein.

GIGAIPC reserves the right to make changes in the product design without notice to its users.

Acknowledgement

All other products' name or trademarks are properties of their respective owners.

- AMD® is trademark of Advanced Micro Devices.
- Microsoft Windows is a registered trademark of Microsoft Corp.
- Intel, Pentium, Celeron, and Xeon are registered trademarks of Intel Corporation
- Core, Atom are trademarks of Intel Corporation
- ITE is a trademark of Integrated Technology Express, Inc.
- IBM, PC/AT, PS/2, and VGA are trademarks of International Business Machines Corporation.

All other product names or trademarks are properties of their respective owners.

Packing List

Before setting up your product, please make sure the following items have been shipped:

Item	Quantity
QBiP-8565A/ QBiP-8265A/ QBiP-8145A	1
SATA power cable	1

If any of these items are missing or damaged, please contact your distributor or sales representative immediately.

About this Document

This User's Manual contains all the essential information, such as detailed descriptions and explanations on the product's hardware and software features (if any), its specifications, dimensions, jumper/connector settings/definitions, and driver installation instructions (if any), to facilitate users in setting up their product.

Users may refer to the GIGAIPC.com for the latest version of this document.

Safety Precautions

Please read the following safety instructions carefully. It is advised that you keep this manual for future references

1. All cautions and warnings on the device should be noted.
2. Make sure the power source matches the power rating of the device.
3. Position the power cord so that people cannot step on it. Do not place anything over the power cord.
4. Always completely disconnect the power before working on the system's hardware.
5. No connections should be made when the system is powered as a sudden rush of power may damage sensitive electronic components.
6. If the device is not to be used for a long time, disconnect it from the power supply to avoid damage by transient over-voltage.
7. Always disconnect this device from any AC supply before cleaning.
8. While cleaning, use a damp cloth instead of liquid or spray detergents.
9. Make sure the device is installed near a power outlet and is easily accessible.
10. Keep this device away from humidity.
11. Place the device on a solid surface during installation to prevent falls
12. Do not cover the openings on the device to ensure optimal heat dissipation.
13. Watch out for high temperatures when the system is running.

14. Do not touch the heat sink or heat spreader when the system is running
15. Never pour any liquid into the openings. This could cause fire or electric shock.
16. As most electronic components are sensitive to static electrical charge, be sure to ground yourself to prevent static charge when installing the internal components. Use a grounding wrist strap and contain all electronic components in any static-shielded containers.
17. If any of the following situations arises, please the contact our service personnel:
 - i. Damaged power cord or plug
 - ii. Liquid intrusion to the device
 - iii. Exposure to moisture
 - iv. Device is not working as expected or in a manner as described in this manual
 - v. The device is dropped or damaged
 - vi. Any obvious signs of damage displayed on the device

18. DO NOT LEAVE THIS DEVICE IN AN UNCONTROLLED ENVIRONMENT WITH TEMPERATURES BEYOND THE DEVICE'S PERMITTED STORAGE TEMPERATURES (SEE CHAPTER 1) TO PREVENT DAMAGE.

FCC Statement

Warning!



This device complies with Part 15 FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received including interference that may cause undesired operation.

Caution:

There is a danger of explosion if the battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions and your local government's recycling or disposal directives.

Attention:

Il y a un risque d'explosion si la batterie est remplacée de façon incorrecte. Ne la remplacer qu'avec le même modèle ou équivalent recommandé par le constructeur. Recycler les batteries usées en accord avec les instructions du fabricant et les directives gouvernementales de recyclage.

China RoHS Requirements (CN)

产品中有毒有害物质或元素名称及含量

GIGAIPC Main Board/ Daughter Board/ Backplane

部件名称	有毒有害物质或元素					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
印刷电路板 及其电子组件	○	○	○	○	○	○
外部信号 连接器及线材	○	○	○	○	○	○

○: 表示该有毒有害物质在该部件所有均质材料中的含量均在 SJ/T 11363-2006 标准规定的限量要求以下。

X: 表示该有毒有害物质至少在该部件的某一均质材料中的含量超出 SJ/T 11363-2006 标准规定的限量要求。

备注: 此产品所标示之环保使用期限, 系指在一般正常使用状况下。

China RoHS Requirement (EN)

Poisonous or Hazardous Substances or Elements in Products GIGAIPC Main Board/ Daughter Board/ Backplane

Component	Poisonous or Hazardous Substances or Elements					
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent Chromium (Cr(VI))	Polybrominated Biphenyls (PBB)	Polybrominated Diphenyl Ethers (PBDE)
PCB & Other Components	○	○	○	○	○	○
Wires & Connectors for External Connections	○	○	○	○	○	○

O : The quantity of poisonous or hazardous substances or elements found in each of the component's parts is below the SJ/T 11363-2006-stipulated requirement.
X: The quantity of poisonous or hazardous substances or elements found in at least one of the component's parts is beyond the SJ/T 11363-2006-stipulated requirement.
Note: The Environment Friendly Use Period as labeled on this product is applicable under normal usage only




Table Contents

3.5" SBC Boards	1
QBiP-8565A/ QBiP-8265A/ QBiP-8145A User's Manual 1st Ed	1
Copyright Notice	2
Acknowledgement	3
Packing List.....	4
About this Document	5
Safety Precautions	6
FCC Statement.....	8
China RoHS Requirements (CN).....	9
China RoHS Requirement (EN)	10
Chapter 1 - Product Specifications	
QBiP-8565A/ QBiP-8265A/ QBiP-8145A	13
1.3 Specifications- QBiP-8565A/ QBiP-8265A/ QBiP-8145A..	15
Chapter 2 – Hardware Information	17
2.1 Jumpers and Connectors	18
2.2.1 CPU FAN (CPU FAN connector)	21
2.2.2 System FAN (System FAN connector)	22
2.2.3 JCOM1 (COM1 RI# pin RI#/5V/12V Select).....	23
2.2.4 COM2, COM3, COM4 (Serial port header)	24
2.2.5 FUSB (USB 2.0 header)	25
2.2.6 SATAIII_0, SATAIII_1 (SATA 6Gb/s Connector).....	26

2.2.7	GPIO_CNT (General Purpose input/output header)	27
2.2.8	SATAPW1, SATAPW2 (SATA 6Gb/s power connector)	28
2.2.9	AT_CN (AT/ATX power mode select jumper)	29
2.2.10	DC_IN (DC IN 1x4-pin power connector)	30
2.2.11	SPK_OUT (Speaker out connector)	31
2.2.12	FP_Audio (Front Audio connector)	32
2.2.13	BKL_CN (Back light brightness control connector)	33
2.2.14	SYS_PANEL (Front panel header)	34
2.2.15	LVDS (LVDS connector)	35
2.2.16	LSW (LVDS resolution jumper)	36
2.2.17	BATTERY (Battery cable connector)	37
2.2.18	LPC_CN (LPC Connector)	38

Chapter 1

Chapter1 - Product Specifications
QBiP-8565A/ QBiP-8265A/ QBiP-8145A



1.3 Specifications- QBiP-8565A/ 8265A/ 8145A


Motherboard	QBiP-8565A	QBiP-8265A	QBiP-8145A
Form Factor	3.5" SBC 146W x 101.7Dmm		
CPU	Intel® Core™ i7-8565U Processor 14nm, 4 cores, 8 threads 1.8GHz, up to 4.6 GHz TDP 15W 8 MB Intel® Smart Cache	Intel® Core™ i5-8265U Processor 14nm, 4 cores, 8 threads 1.6GHz, up to 3.9 GHz TDP 15W 6 MB Intel® Smart Cache	Intel® Core™ i3-8145UE Processor 14nm, 2 cores 2.2GHz up to 3.90 GHz TDP 15W 4 MB Intel® Smart Cache
Socket	1 x FCBGA1528		
Chipset	—		
Memory	2 x DDR4 SO-DIMM sockets, Max. Capacity 32 GB Dual channel memory architecture Support for DDR4 2400 MHz memory modules		
Ethernet	2 x GbE LAN ports (Intel® i219V and Intel® i211AT)		
Video	Integrated Graphics Processor - Intel® UHD Graphics 620 2 x HDMI1.4 port, supporting a maximum resolution of 4096x2304@24Hz 1 x LVDS port, supporting a maximum resolution of 1920 x 1080@60Hz * Support up to 3 displays at the same time		
Audio	Realtek ALC269 High Definition Audio		
Storage	2 x SATA 6Gb/s ports		
Raid	Intel® SATA RAID 0/1/5		
Expansion Slots	1 x M.2 slot: - M-key - SATA 6Gb/s / PCIe X4 - Supports NGFF-2280 cards 1 x M.2 slot: - E-key - Supports NGFF-2230 (WiFi/BT) 1 x Mini-PCIe slot - Full card size - Support PCIe X1+USB2.0 --support 3G/4G module		

Motherboard	QBiP-8565A	QBiP-8265A	QBiP-8145A
Internal I/O	1 x 4 pin box header (DC in) 2 x SATA 6Gb/s connectors 1 x CPU fan header 1 x System fan header 1 x Front panel header 1 x Front panel audio header 1 x 2W Speaker out header 2 x SATA Power headers 2 x USB 2.0/1.1 headers 1 x GPIO (8 bits) & SMBUS header 3 x COM headers (RS-232) 1 x Backlight control header 1 x AT/ATX mode select jumper 1 x 3G Sim Slot 1 x LVDS connector		
Rear I/O	1 x COM Port (RS232/422/485 and RI/5V/12V) 2 x HDMI 2 x RJ45 4 x USB3.1 Gen2		
TPM	1 x TPM Header		
OS Compatibility	Windows® 10 (x64)		
PSU Connectors	1 x 4-pin Box header power connector (9~36V Full Range) (48V option)		
Operating Properties	Operating temperature: 0°C to 60°C Operating humidity: 0-90% (non-condensing) Non-operating temperature: -40°C to 85°C Non-operating humidity: 0%-95% (non-condensing)		

Chapter 2


Chapter 2 – Hardware Information

2.1 Jumpers and Connectors




No	Code	Description
1	CPU FAN	CPU FAN connector
2	SYS FAN	System FAN connector
3	JCOM1	COM1 (COM RI# pin RI#/5V/12V Select)
4	COM2 COM3 COM4	Serial port header
5	FUSB	USB 2.0 header
6	SATAIII1 SATAIII0	SATA 6GB/S Connector
7	GPIO_CNT	General purpose input/output header
8	SATAPW1 SATAPW2	SATA 6Gb/s power connector
9	AT_CN	AT/ATX power mode select jumper
10	DC_IN	DC IN 1x4pin power connector
11	SPK_OUT	Speaker out connector
12	FP_Audio	Front Audio connector
13	BKL_CN	Back light brightness control connector
14	SYS_PANEL	Front panel header
15	LVDS	LVDS connector
16	LSW	LVDS resolution jumper
17	BATTERY	Battery cable connector
18	LPC_CN	LPC Connector
19	SODIMM1 SODIMM2	DDR4 SO-DIMM Slot

No	Code	Description
20	M2E	M.2 Slot, E-key, NGFF2230, WiFi & Bluetooth module
21	MPCIE	Mini PCIe full size, support 3G/4G module
22	M2M	M.2 Slot, SATA/PCIeX4, NGFF2280
23	SIM-CARD	Sim Card slot
24	RUSB31_1 RUSB31_2	USB3.1 Connector x 4
25	HDMI21	HDMI connector
26	LAN1, LAN2	LAN connector
27	COM1	Serial Port connector




2.2.1 CPU FAN (CPU FAN connector)

1



CPU FAN connector





Connector PN	Vendor
85205-0470N	ACES
A1250WV-S-04PC	JOINT-TECH

Pin No.	Definition
1	GND
2	12V
3	Detect
4	Speed Control

2.2.2 System FAN (System FAN connector)

2




Connector PN	Vendor
85205-0470N	ACES
A1250WV-S-04PC	JOINT-TECH

Pin No.	Definition
1	GND
2	12V
3	Detect
4	Speed Control

2.2.3 JCOM1 (COM1 RI# pin RI#/5V/12V Select)

3





JCOM11 Jumper Select	
	1-2 Close: 5V (Power COM)
	3-4 Close: RI (Stand COM) (Default-Setting)
	5-6 Close: 12V (Power COM)

Connector PN	Vendor
220-97-03GB01	PINREX
PH06N53BAZ000	HORNGTONG

2.2.4 COM2, COM3, COM4 (Serial port header)

4




Connector PN	Vendor
725-81-10TW00	PINREX
A2004WV-2X05P46	JOINT-TECH


Pin No.	Definition
1	RXD
2	DCD
3	DTR
4	TXD
5	DSR
6	GND
7	CTS
8	RTS
9	No Connect
10	RI/ 5V/ 12V

2.2.5 FUSB (USB 2.0 header)

5



USB 2.0 Header




Connector PN	Vendor
210-92-05GB04	PINREX
PH10R53BAZ009	HORNGTONG

Pin No.	Definition
1	5V
2	5V
3	DX-
4	DY-
5	DX+
6	DY+
7	GND
8	GND
9	No Pin
10	No Connect

2.2.6 SATAIII_0, SATAIII_1 (SATA 6Gb/s Connector)

6




SATA Connector	
↙	↘
↙	↘

SATAIII_1,SATAIII_0	
Connector PN	Vendor
WATM-07ABNB2BAUW3	WINWIN
770-83-07SW19	PINREX


Pin No.	Definition
1	GND
2	TXP
3	TXN
4	GND
5	RXN
6	RXP
7	GND

2.2.7 GPIO_CNT (General Purpose input/output header)

7



GPIO Connector



Connector PN

725-81-12TW00

A2004WV-2X06P46

Vendor

PINREX


JOINT-TECH

Pin No. **Definition**

1	GPO1
2	GPI1
3	GPO2
4	GPI2
5	GPO3
6	GPI3
7	GPO4
8	GPI4
9	SMB_CLK
10	SMB_DATA
11	5V
12	GND

2.2.8 SATAPW1, SATAPW2 (SATA 6Gb/s power connector)

8



Hard Disk Power Connector



Connector PN

743-81-04TW00
WF04Q2-3BJQ000

Vendor

PINREX
HORNGTONG


Pin No.

Definition

Pin No.	Definition
1	12V
2	GND
3	GND
4	5V

2.2.9 AT_CN (AT/ATX power mode select jumper)

9



AT/ATX power mode select jumper




Connector PN	Vendor
220-96-03GB01	PINREX
PH03N2-7BAN000	HORNGTONG

Pin No.	Definition
1	AT MODE
2	TXD5
3	ATX MODE

Jumper setting
 1-2 Close : AT mode.
 2-3 Close : ATX mode.(Default setting)

2.2.10 DC_IN (DC IN 1x4-pin power connector)

10



DC in connector



Connector PN

753-81-04TW00


Vendor

PINREX

Pin No.	Definition
1	GND
2	Power
3	Power
4	GND


2.2.11 SPK_OUT (Speaker out connector)

11



Pin 1

Audio Amplifie Connector





1

Connector PN	Vendor
721-81-045W00	PINREX
A2001WV-04P146	JOINT-TECH

Pin No.	Definition
1	Speaker Out L+
2	Speaker Out L-
3	Speaker Out R-
4	Speaker Out R+

2.2.12 FP_Audio (Front Audio connector)

12




Pin No.	Definition
1	MIC_L
2	GND
3	MIC_R
4	Detect
5	HPOUT_R
6	MIC_JD
7	FAUDIO_JD
8	No Connect
9	HPOUT_L
10	GND

Connector PN	Vendor
725-81-10TW00	PINREX
A2004WV-2X05P46	JOINT-TECH

2.2.13 BKL_CN (Back light brightness control connector)

13



Back light brightness control connector



Connector PN

A2001WV-05P146

Vendor

JOINT-TECH

Pin No.	Definition
1	5V
2	PWM
3	Back Light Enable
4	GND
5	12V

Connector PN


721-81-05TW00

Vendor

PINREX

2.2.14 SYS_PANEL (Front panel header)

14



Pin 1


System Panel Header	
2	10
1	9

Connector PN	Vendor
210-92-05G111	PINREX


Pin No.	Definition
1	HDD LED+
2	Power LED+
3	HDD LED-
4	Power LED-
5	GND
6	Power Button+
7	Reset Button
8	Power Button-
9	No Connect
10	No Pin

2.2.15 LVDS (LVDS connector)

15



LVDS Connector



Connector PN

Vendor

712-76-40GWE0

PINREX


A1252WV-SF-2X20PD01

JOINT-TECH

Pin No.	Definition	Pin No.	Definition
1	3.3V	21	A5+
2	5V	22	A4+
3	3.3V	23	A5-
4	5V	24	A4-
5	SPE00	25	GND
6	SPED0	26	GND
7	GND	27	A7+
8	GND	28	A6+
9	A1+	29	A7-
10	A0+	30	A6-
11	A1-	31	GND
12	A0-	32	GND
13	GND	33	CLK2+
14	GND	34	CLK1+
15	A3+	35	CLK2-
16	A2+	36	CLK1-
17	A3-	37	GND
18	A2-	38	GND
19	GND	39	12V
20	GND	40	12V

2.2.16 LSW (LVDS resolution jumper)

16




Pin 1

LVDS Resolution Jumper			
Jumper Setting	Resolution	Jumper Setting	Resolution
1 8 8	800 x 600 18bit	1 8 8	1366 x 768 24bit
1 8 8	1024 x 768 18bit	1 8 8	1440 x 900 24bit
1 8 8	1024 x 768 24bit	1 8 8	1400 x 1050 24bit
1 8 8	1024 x 600 18bit	1 8 8	1600 x 900 24bit
1 8 8	1280 x 800 18bit	1 8 8	1680 x 1050 24bit
8 1	1024 x 600 18bit	1 8 8	1600 x 1200 24bit
1 8 8	1280 x 1024 24bit	1 8 8	1920 x 1080 24bit
1 8 8	1366 x 768 18bit	1 8 8	1920 x 1200 24bit


Connector PN	Vendor
222-97-04GBE1	PINREX

2.2.17 BATTERY (Battery cable connector)

17



Battery Cable Connector



Connector PN

85205-0270L
A1250WV-S-02PC

Vendor

ACES
JOINT-TECH

Pin No.

Definition

1

3.3V

2

GND